

Network Installation Guide

WorkForce[®] 610 Series

Artisan[®] 710 Series

Contents

Before You Begin	3
Choose Your Connection Type	4
Wireless	4
Wired	4
Wireless Network Installation	5
Connect Wirelessly Using the Setup Wizard	5
Connect Wirelessly Using Advanced Setup	9
Create an Ad-Hoc Wireless Connection	16
Wired (Ethernet) Installation	23
Install Software	24
Finish the Installation	28
Windows	28
Macintosh	29
Troubleshooting	30
Setup Problems	31
Printing Problems	33
Scanning Problems	34
Print a Network Status Sheet	35
Copyright Notice	35

Before You Begin

Make sure you installed ink cartridges and loaded paper as described on the *Start Here* sheet. Then follow the instructions in this guide to set up the printer for use on a network.

Tip:

For a video tutorial and other information about setting up a wireless network, go to: epson.com/support/wireless.


Do one of the following:

- If you're installing the printer for the first time, see "Choose Your Connection Type" on page 4.
- If you're setting up an additional computer to use the printer on the network, follow the steps in "Install Software" on page 24.

Choose Your Connection Type



Wireless To connect the printer wirelessly, see page 5.




Note:

If you want to print wirelessly but do not have an access point or router, see “Create an Ad-Hoc Wireless Connection” on page 16.



Wired To connect the printer using an Ethernet cable, see page 23.





Wireless Network Installation

To connect to your printer wirelessly, you need to know the name (SSID) of your wireless network. If it has security enabled, you also need to know the WEP key or WPA passphrase. Write down your network and security information in the space provided below:

■ Network name (SSID): _____

■ WEP key or WPA passphrase: _____

Note:

Your printer is compatible with 802.11b and 802.11g. If your router or access point supports 802.11n (Wireless N), make sure it is set to compatibility mode to allow 802.11b and 802.11g devices to connect to it.

Your printer supports the following wireless security modes: WEP, WPA, and WPA2.

If you don't know your wireless network name (SSID), WEP key, or WPA passphrase, contact the person who set up your wireless network before you begin.

If your WPA passphrase contains upper- or lowercase letters, be sure to note it correctly.


Connect Wirelessly Using the Setup Wizard

Follow the steps below to connect to your printer wirelessly.


1. Select **Setup** on the printer's control panel, then press OK.




2. Press **◀** or **▶** to select **Network Settings**, then press OK.




3. Press OK to select **Wireless LAN Setup**.



4. Press OK to select **Wireless Setup Wizard**.



5. Press ▲ or ▼ to select the name of your wireless network, then press OK.






If your network name isn't listed, try the following:

- Make sure that your wireless router or access point is turned on and working correctly. Press the ⏪ **Back** button to return to the previous screen, press **OK** to select **Wireless Setup Wizard**, then repeat step 5.
 - If you still can't find the network name in the list, your router or access point is not broadcasting its network name. Press the ⏪ **Back** button, then see "Connect Wirelessly Using Advanced Setup" on page 9.
6. Do one of the following:
 - If your wireless network doesn't have security enabled, continue with step 9.
 - If your wireless network has security enabled, continue with step 7.

6 Wireless Network Installation

7. Use the arrow buttons on the printer's control panel to enter your WEP key or WPA passphrase. Press the **Menu** button to switch between uppercase, lowercase, or numeric/special characters.




From the printer's control panel:
Press ▲ or ▼ to select a character.
Press ◀ or ▶ to move the cursor.
Press - to delete a character.
Press OK when done.

Important:


WPA passphrases and WEP keys in ASCII format are case-sensitive. Be sure to enter upper- or lowercase letters as necessary.

- Press **Menu** to switch between uppercase (ABC), lowercase (abc), or numeric/special (123) characters.
 - Press ▲ or ▼ until you see the character you want.
 - Press ◀ or ▶ to move the cursor.
 - Press - to delete a character.
8. When you're done entering your WEP key or WPA passphrase, press OK.

- When you see a screen like this one, verify that the settings are correct. If you need to change a setting, press **⏪ Back** until you see the setting you need to change.



- Once you have verified that your network settings are correct, press **OK** to save the settings and return to the Network Settings menu.



- Press the **Home** button to exit the Network Settings Menu.
- Wait for the printer to connect to your wireless network (this can take up to 90 seconds).

Once it's connected, you see the  WiFi icon and a signal strength indicator on the printer's control panel.

- Continue with "Install Software" on page 24.

Note:

If the printer doesn't connect to your wireless network after 90 seconds, the WEP key or WPA passphrase may have been entered incorrectly. See "Connect Wirelessly Using the Setup Wizard" on page 5 to select your network settings again.

If the printer still doesn't connect to your wireless network, see "The printer cannot find or connect to the wireless router or access point" on page 31.


Connect Wirelessly Using Advanced Setup

Use this setup method if your access point or router isn't broadcasting its network name (SSID). Make sure you know the type of security your access point or router uses (WEP, WPA, or WPA2), and the key or passphrase.


1. Select **Setup** on the printer's control panel, then press **OK**.




2. Press **◀** or **▶** to select **Network Settings**, then press **OK**.




3. Press **OK** to select **Wireless LAN Setup**.




4. Press **▲** or **▼** to select **Advanced Setup**, then press **OK**.




5. Press ▲ or ▼ to select Manual Wireless LAN Setup, then press OK.




6. When you see this screen, press OK.







7. Press ▲ or ▼ to select Infrastructure Mode, then press OK.








8. Press ▲ or ▼ to select Enter SSID, then press OK.









9. Use the arrow buttons on the printer's control panel to enter your wireless network name (SSID). Press the  **Menu** button to switch between uppercase, lowercase, or numeric/special characters.



From the printer's control panel:
Press  or  to select a character.
Press  or  to move the cursor.
Press  to delete a character.
Press **OK** when done.


Important:

Network names are case-sensitive. Be sure to enter upper- or lowercase letters as necessary.

- Press  **Menu** to switch between uppercase (**ABC**), lowercase (**abc**), or numeric/special (**123**) characters.
- Press  or  until you see the character you want.
- Press  or  to move the cursor.
- Press  to delete a character.

10. When you're done entering your wireless network name, press **OK**.

11. Press ▲ or ▼ to select the security mode that your wireless network is using, then press OK.




Note:




If your wireless network doesn't have security enabled, select **None**, then press **OK**.

12. Do one of the following:

- If your wireless network uses WPA or WPA2 as the security mode, continue with "Select WPA Security Settings" on page 13.
- If your wireless network uses WEP as the security mode, continue with "Select WEP Security Settings" on page 14.
- If your wireless network doesn't have security enabled, continue with "Confirm Your Network Settings" on page 15.

Select WPA Security Settings


1. Use the arrow buttons on the printer's control panel to enter your WPA passphrase. Press the  Menu button to switch between uppercase, lowercase, or numeric/special characters.



From the printer's control panel:
Press ▲ or ▼ to select a character.
Press ◀ or ▶ to move the cursor.
Press - to delete a character.
Press OK when done.

Important:

WPA passphrases are case-sensitive. Be sure to enter upper- or lowercase letters as necessary.

- Press  Menu to switch between uppercase (ABC), lowercase (abc), or numeric/special (123) characters.
 - Press ▲ or ▼ until you see the character you want.
 - Press ◀ or ▶ to move the cursor.
 - Press - to delete a character.
2. When you're done entering the WPA passphrase, press OK.
 3. Continue with "Confirm Your Network Settings" on page 15.



Select WEP Security Settings

1. Press ▲ or ▼ to select **Alphanumeric** if your WEP key is ASCII, or select **Hexadecimal** if your WEP key is in hexadecimal format.

Note:

If the WEP key is 5 or 13 characters, it's ASCII. If the WEP key is 10 or 26 characters, it's hexadecimal.

2. Use the arrow buttons on the printer's control panel to enter your WEP key. Press the ≡ **Menu** button to switch between uppercase, lowercase, or numeric characters.



From the printer's control panel:
Press ▲ or ▼ to select a character.
Press ◀ or ▶ to move the cursor.
Press - to delete a character.
Press OK when done.


Important:

WEP keys in ASCII format are case-sensitive. Be sure to enter upper- or lowercase letters as necessary.


- Press **≡ Menu** to switch between uppercase (ABC), lowercase (abc), or numeric (123) characters.
 - Press **▲** or **▼** until you see the character you want.
 - Press **◀** or **▶** to move the cursor.
 - Press **–** to delete a character.
3. When you're done entering the WEP key, press **OK**.
 4. Continue with the next section.

Confirm Your Network Settings

1. When you see a screen like this one, verify that the settings are correct. If you need to change a setting, press **↵ Back** until you see the setting you need to change.




2. Once you have verified that your network settings are correct, press **OK** to save the settings and return to the Network Settings menu.



3. Press the **Home** button to exit the Setup menu.

4. Wait for the printer to connect to your wireless network (this can take up to 90 seconds).

Once it's connected, you see the  WiFi icon and a signal strength indicator on the printer's control panel.

5. Continue with "Install Software" on page 24.

Note:

If the printer doesn't connect to your wireless network after 90 seconds, the SSID, WEP key, or WPA passphrase may have been entered incorrectly. See "Connect Wirelessly Using Advanced Setup" on page 9 to select your network settings again.

If the printer still doesn't connect to your wireless network, see "The printer cannot find or connect to the wireless router or access point" on page 31.

Create an Ad-Hoc Wireless Connection

Use this setup method if you want to print wirelessly but do not have an access point or router.

Important:

For Windows® users: If your computer is connected to a network with an Ethernet cable, you need to disconnect it before installing software. When setup is complete, reconnect your computer's Ethernet cable.

For Macintosh® users: If your computer is connected to a network with an Ethernet cable or you use a modem for Internet access, you cannot set up your printer this way. See "Connect Wirelessly Using the Setup Wizard" on page 5 or "Wired (Ethernet) Installation" on page 23 to set up your printer.


1. Select  **Setup** on the printer's control panel, then press **OK**.




2. Press ◀ or ▶ to select Network Settings, then press OK.




3. Press OK to select Wireless LAN Setup.




4. Press ▲ or ▼ to select Advanced Setup, then press OK.




5. Press ▲ or ▼ to select Manual Wireless LAN Setup, then press OK.




- When you see this screen, press OK.







- Press ▲ or ▼ to select Ad Hoc Mode, then press OK.



- Press ▲ or ▼ to select Enter SSID, then press OK.




9. Use the arrow buttons on the printer's control panel to create a unique network name (SSID) to identify your printer. Press the  Menu button to switch between uppercase, lowercase, or numeric/special characters.



From the printer's control panel:
Press ▲ or ▼ to select a character.
Press ◀ or ▶ to move the cursor.
Press - to delete a character.
Press OK when done.

Important:

Network names are case-sensitive. Be sure to enter upper- or lowercase letters as necessary.

- Press  Menu to switch between uppercase (ABC), lowercase (abc), or numeric/special (123) characters.
- Press ▲ or ▼ until you see the character you want.
- Press ◀ or ▶ to move the cursor.
- Press - to delete a character.


10. Press **OK** to select the default channel for your Ad Hoc network.



11. Continue with the next section.

Choose Security Settings

1. Press **▲** or **▼** to select the security mode you want to use for the Ad Hoc wireless network, then press **OK**.



Note:

If you don't want to enable security for your Ad Hoc network, select **None**, then press **OK**.

2. Do one of the following:


- If you selected **None** as the security mode, continue with “Confirm Your Settings and Connect to the Network” on page 22.
- If you selected **WEP** as the security mode, continue with step 3.



3. Create a WEP key for the Ad Hoc network. The WEP key can be in alphanumeric (ASCII) format (recommended) or hexadecimal format.

Note:

An alphanumeric WEP key must be 5 or 13 characters. A hexadecimal WEP key must be 10 or 26 characters.

4. Press **▲** or **▼** to select **Alphanumeric** if your WEP key is ASCII, or select **Hexadecimal** if your WEP key is in hexadecimal format.


- Use the arrow buttons on the printer's control panel to enter your WEP key. Press the  **Menu** button to switch between uppercase, lowercase, or numeric characters.



From the printer's control panel:
 Press ▲ or ▼ to select a character.
 Press ◀ or ▶ to move the cursor.
 Press - to delete a character.
 Press OK when done.


Important:

WEP keys in ASCII format are case-sensitive. Be sure to enter upper- or lowercase letters as necessary.


- Press  **Menu** to switch between uppercase (ABC), lowercase (abc), or numeric (123) characters.
 - Press ▲ or ▼ until you see the character you want.
 - Press ◀ or ▶ to move the cursor.
 - Press - to delete a character.
- When you're done entering the WEP key, press OK.
 - Continue with the next section.

Confirm Your Settings and Connect to the Network

1. When you see a screen like this one, verify that the settings are correct. If you need to change a setting, press **⏪ Back** until you see the setting you need to change.



2. Once you have verified that your network settings are correct, press **OK** to save the settings and return to the Network Settings menu.




3. Press the **Home** button to exit the Setup menu.
4. On your computer, connect to the wireless network name you created on page 19 (see your computer or wireless adapter's documentation for details).
5. Continue with "Install Software" on page 24.




Wired (Ethernet) Installation

1. Connect an Ethernet network cable to the LAN (10/100) port on your printer.



2. Connect the other end to any available LAN port on your router, access point, or hub.




Note:

If you're switching from a wireless to a wired network connection, you need to disable the wireless adapter using the printer's control panel. Select **Setup** on the printer's control panel, select **Network Settings > Wireless LAN Setup > Advanced Setup > Disable Wireless LAN**. Select **Yes**, then press **OK**.

3. Continue with the next section to install software.

Install Software

Follow these steps for each computer you want to use with your printer over the network. The screens show the WorkForce 610 Series, but the steps are the same for the Artisan 710 Series.

1. Insert the printer software CD.
2. **Windows Vista®:** If you see the AutoPlay window, click **Run SETUP.EXE**. When you see the User Account Control screen, click **Continue**.
Windows® XP: When you see the Software Installation screen, go to step 3.
Mac OS® X: Double-click the  icon.
3. Click **Install**.



4. When you see this screen, select **Install driver for network connection** and click **Next**.



- When you see this screen, click **Next** to start network setup.



- Make sure that your printer is turned on and connected to your network.
- When you see the Firewall Warning screen, click **Next**.




Note:

If you see a firewall alert message, click **Unblock** or **Allow** to let EpsonNet Setup continue. Do not select **Ask Me Later**, **Keep Blocking**, or **Block**.


If you don't allow EpsonNet Setup to continue, you will not be able to install your printer. You might need to contact your firewall provider for assistance.

8. Wait while EpsonNet Setup configures your printer for the network.




9. Do one of the following:


- If you see the Installation Complete screen, continue with the instructions for finishing the installation for Windows on page 28 or Macintosh on page 29.



- If no available printers are found on your network, see “EpsonNet Setup was unable to find my printer on the network” on page 32.



- If EpsonNet Setup finds more than one printer on your network, select the printer you want to configure, then click **Next**. When you see the Installation Complete screen, continue with “Finish the Installation” on page 28.
- If you are installing the printer in Ad Hoc mode and you see this screen, make sure your computer’s wireless adapter is set to assign IP addresses automatically. Then select **Acquire the IP Address Automatically using DHCP (Recommended)** and click **Next**. When you see the Installation Complete screen, continue with the steps on the next page.




Finish the Installation

Follow the steps for your operating system:

- “Windows” below
- “Macintosh” on page 29

Windows

1. Print a test page, then click Finish.




2. Follow the prompts on the screen to install bonus software and finish the installation.
3. When installation is complete, restart your computer.


You're ready to scan and print. See your printed documentation and on-screen *Epson Information Center* for details.

Macintosh

1. Click **Save** to install an application that allows you to access the printer's memory card slots over the network.



2. Select where you would like to install the application, then click **Save**.



3. Click **Finish**.

4. When you see this screen, click **Add Printer**.



5. Follow the steps on the right side of the screen to add your EPSON TCP/IP printer.

Note:

It may take up to 90 seconds for your computer to find the EPSON TCP/IP printer on the network.

6. Follow the prompts on the screen to print a test page, install bonus software, and finish the installation.
7. When installation is complete, restart your computer.

You're ready to scan and print. See your printed documentation and on-screen *Epson Information Center* for details.

Troubleshooting

If you have problems setting up or using your product on a network, check these sections for help:

- “Setup Problems” below
- “Printing Problems” on page 33
- “Scanning Problems” on page 34

This section also explains how to print a Network Status Sheet (see page 35).


Setup Problems


The printer cannot find or connect to the wireless router or access point

- Try connecting to the wireless router or access point with your computer or another device to confirm that it is working correctly.
- Make sure that the printer is within range of your router or access point.
- Avoid placing the printer near a microwave oven, 2.4 GHz cordless phone, or large metal object such as a filing cabinet.
- Make sure there aren't any access restrictions (such as MAC address filtering) set on the wireless router or access point. If access restrictions are set, register the printer's MAC address on the router or access point. Print a Network Status Sheet (see page 35) to obtain the MAC address. Then see your router or access point's documentation for instructions.
- If your wireless router or access point doesn't broadcast its network name (SSID), see "Connect Wirelessly Using Advanced Setup" on page 9 for instructions on connecting to your wireless network. If your wireless router or access point has wireless security enabled, you will also need to know what kind of security it is using.
- If the printer doesn't connect to your wireless network, the WEP key or WPA passphrase may have been entered incorrectly. See "Wireless Network Installation" on page 5 to select your network settings again.
- The printer is compatible with 802.11b and 802.11g. If your router or access point supports 802.11n (Wireless N), make sure that it is set to compatibility mode to allow 802.11b and 802.11g devices to connect to it.
- If your network has a firewall and you did not allow access when you installed the software, you will need to reinstall the software following the instructions on page 24. You might need to contact your firewall provider for assistance.

EpsonNet Setup was unable to find my printer on the network

1. If you see a screen like this one, do one of the following:



- If you connected the printer wirelessly, verify that the printer is turned on and the  WiFi icon appears on the printer's control panel. Select **WiFi setup using the printer's control panel**, then click **Next**.
- If you connected the printer to your network with an Ethernet network cable, verify that the printer is turned on and connected to your network. Select **Wired Network (Ethernet) setup**, then click **Next**.
- If you created an Ad-Hoc wireless connection, do one of the following:
 - **For Windows users:** If your computer is connected to a network with an Ethernet cable, disconnect it. When setup is complete, reconnect your computer's Ethernet cable.
 - **For Macintosh users:** If your computer is connected to a network with an Ethernet cable, you cannot set up your printer this way. See page 5 or page 23 to set up your printer.
 - If you're switching from a wireless to a wired network connection, you need to disable the wireless adapter using the printer's control panel. Select **Setup** on the printer's control panel, select **Network Settings > Wireless LAN Setup > Advanced Setup > Disable Wireless LAN**. Select **Yes**, then press **OK**.

2. Continue clicking **Next** until EpsonNet Setup begins to search for your printer. Then continue with step 9 on page 26.

Software installation failed

Make sure that the printer is connected to your network (see page 5 for wireless or page 23 for Ethernet). Then remove and reinsert the CD to reinstall the printer software.

Cannot communicate on a wired LAN

If you're switching from a wireless to a wired network connection, you need to disable the wireless adapter using the printer's control panel. Select **Ⓜ Setup** on the printer's control panel, select **Network Settings > Wireless LAN Setup > Advanced Setup > Disable Wireless LAN**. Select **Yes**, then press **OK**.

The printer does not appear in the Add Printer window (Mac OS X)

Make sure the printer driver was installed correctly and that your computer's TCP/IP settings are configured correctly.

Cannot access a memory card over the network

- Remove the memory card from the printer. Select **Ⓜ Setup** on the printer's control panel, then select **Network Settings > File Sharing Setup > Network > Read/Write**. Press **OK**, then press **OK** again to update the setting.
- For Macintosh, follow the instructions on page 29 to install an application that allows you to access the printer's memory card slots over the network.

Printing Problems

Cannot print over the network


- For wireless connections, print a Network Status Sheet (see page 35). If the Link Status is Disconnected, make sure the wireless router or access point is turned on and the settings are correct for your wireless network.
- For wired connections, print a Network Status Sheet (see page 35) and make sure the settings are correct for your network.

If the Network Status is Disconnected, try the following:

- Make sure the Ethernet cable is securely connected to both the printer and your router, access point, switch, or hub.
- Try connecting to another port on your router, access point, switch, or hub.

- Try connecting the printer to another router, access point, switch, or hub.
- Try connecting the printer to your router, access point, switch, or hub with another Ethernet cable.
- When using TCP/IP, make sure the printer's IP address is set correctly for your network. If your network does not assign IP addresses using DHCP, you need to set the IP address manually.

Printing is slow or the print is cut off

For wireless connections, print a Network Status Sheet (see below) and check the Signal Strength. Or check the number of bars next to the  WiFi icon on the printer's control panel. If the Signal Strength is poor or you see only one or two bars, try moving the printer closer to your wireless router or access point. Avoid placing the printer next to a microwave oven, 2.4 GHz cordless phone, or large metal objects such as a filing cabinet.

A dial-up connection dialog box appears when printing with EpsonNet Print

If you use a dial-up connection for Internet access, you will see this message every time you print. Try connecting to the Internet using a LAN connection or set your dial-up connection to dial manually (Never dial a connection).

Scanning Problems

Cannot find the scanner or start Epson Scan

- If network communication was interrupted while starting Epson Scan, exit Epson Scan, and restart it after a few seconds. If Epson Scan cannot restart, turn the printer off and back on, and then try restarting Epson Scan. Check the Timeout Setting in EPSON Scan Settings. For details, see the Epson Scan Help.
- If you have a firewall or Internet security software installed, the search feature in EPSON Scan Settings may not work correctly. In this case, print a Network Status Sheet (see below), click EPSON Scan Settings > Add > Enter address, and enter the IP address manually.
- If you are scanning a large document at high resolution, a communication error may occur. If the scan did not complete, lower the resolution.

Print a Network Status Sheet

1. If necessary, select **Setup** on the printer's control panel to enter the Setup menu.
2. Select **Network Settings**.
3. Select **Confirm Network Settings**.
4. Press the **Start** button to print a network status sheet.

Copyright Notice

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson product. Epson is not responsible for any use of this information as applied to other equipment.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Software License Agreements

In addition to software program rights owned by Seiko Epson Corporation, this product also includes open-source software. See the "Software Notices" section in the online *Epson Information Center* for a list of open-source software and software license terms applied to this printer.

Trademarks

Epson is a registered trademark and Epson Exceed Your Vision is a registered logomark of Seiko Epson Corporation.

WorkForce and Artisan are registered trademarks of Epson America, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This information is subject to change without notice.

© 2009 Epson America, Inc. 4/09



411688600

CPD-27498
Printed in XXXXXX