

2019 Audi Maintenance Schedule - All Models

MY 2019 Maintenance Intervals - USA

This applies only to the following vehicles:

A3, S3, RS 3, A3 e-tron, A4, A4 allroad, A5, S5, RS 5, A6 6-cylinder, A7, A8L, Q5, SQ5, Q7, Q8, TT, TTS, TT RS

| Service intervals in miles | | | | | | | | | | | | |
|---|---|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|
| | 10K | 20K | 30K | 40K | 50K | 60K | 70K | 80K | 90K | 100K | 110K | 120K |
| Minor Maintenance (Every-1 year) ¹ | х | | х | | х | | Х | | х | | Х | |
| Standard Maintenance (Every 2 years) ² | | Х | | х | | Х | | Х | | х | | х |
| Additional Maintenance Items | Refer to the Additional Maintenance Items Table below | | | | | | | | | | | |

¹⁾ First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.

NOTE: The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Check all completed items

sive play

| Mi | nor Maintenance |
|-----|--|
| | Brake system - Check the thickness of the brake pads Engine oil and oil filter - Change oil and replace filter Multi-point inspection - Complete Service reminder indicator display - Reset display |
| | Tire repair kit - Check and record the completeness and expiration date (if equipped) |
| Sta | andard Maintenance (Includes All Minor Maintenance Items) |
| | Body/chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open |
| | Brake system - Check for damage and leaks, condition of brake hoses and the presence of the bleeder caps; Check the thickness of the brake pads. |
| | Charging socket - Check for contamination and damage (A3 e-tron® only) |
| | Connected box battery - Check state of health with Vehicle Diagnostic Tester in Guided Functions (A4, S4, A4 allroad®, A5, S5, RS 5, A6, A7, A8, Q5, SQ5, Q7, and Q8) |
| | Convertible top - Lubricate latch mechanism (A5 Cabriolet, S5 Cabriolet only) |
| | Cooling system for electrical components - Check coolant level (A3 e-tron® only) |
| | Door hinge (including door stay) and door latch - Lubricate |
| | Engine cooling system - Check freeze protection and coolant level (All except e-tron®) |
| | Engine oil and oil filter - Change oil and replace filter |
| | Engine, transmission, final drive, steering - Visual inspection for leaks and damage |
| | Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, license plate lights |
| | and hazard warning lights |
| | First aid kit - Check and enter expiration date YYYY / MM |
| | Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for exces- |

1

8/27/2018

²⁾ First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.



Standard Maintenance (continued)

| Headlights - Check adjustment |
|--|
| Hood safety catch – Lubricate (A3, A3 Cabriolet, A3 e-tron®, S3, RS 3 only) |
| Horn - Check function |
| Instrument cluster - Check warning and indicator lights |
| Interior lights - Check all interior lights, trunk lights, and glove box compartment illumination |
| Multi-point inspection - Complete |
| Panoramic sunroof systems - Check drainage system by fluid check according to Elsa (if equipped) |
| Plenum chamber and water drain valves: Check for dirt. (A8, Q7, Q8 only) |
| NOTE: Time spent cleaning of item is a separate charge for service time |
| Road test - Perform |
| Rollover protection - Check the rollover protection when the convertible top is open (A3 Cabriolet) |
| |
| Service reminder indicator display - Reset display |
| Spare tire - Check condition and tire inflation pressure, adjust if necessary (if equipped) |
| Spoiler - Lubricate rear spoiler (TT, TT Roadster only) |
| |
| Tires - Check condition and tire tread wear. Check and record the tread depth |
| Tires - Check tire inflation pressure and adjust if necessary |
| Tire repair kit - Check and record the completeness and expiration date (if equipped) |
| Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted |
| Warning triangle - Check if present (if equipped) |
| Windshield washer and headlight washing system - Add fluid if necessary. Check adjustment and function |
| Wiper blades - Check condition and replace if necessary |

| | Additional Maintenance Items | | | | | | |
|---|---|---|---|--|--|--|--|
| W | ork to be completed | Interval | Model Application | | | | |
| | Air filter - Replace | Every 60,000 miles | All vehicles | | | | |
| | AWD clutch - Change fluid (if equipped) | Every 3 years regardless of mileage | A3 quattro®, S3, RS 3, TT, TT Roadster, TTS, TT RS Coupe | | | | |
| | Brake fluid - Change | Every 2 years regardless of mileage | All vehicles | | | | |
| | Dust and Pollen filter - Replace | Every 20,000 miles or 2 years, whichever occurs first | All vehicles | | | | |
| | Fragrance Cartridges - Change (if equipped) | Every 2 years regardless of mileage | A6, A7, A8, Q8 only | | | | |
| | Rear Axle, quattro® Sport - Oil and ATF fluid changes | Every 60,000 miles | RS 5 only | | | | |
| | Ribbed V-belt compressor drive - Replace | Every 60,000 miles | Q7 6-cylinder only | | | | |
| | Ribbed V-belt starter/generator drive (including tensioner) - Replace | Every 60,000 miles | A6 4-cylinder only | | | | |
| | Spark plugs - Replace | Every 30,000 miles or 3 years, whichever occurs first | RS 3, RS 5, TT RS Coupe only | | | | |
| | Spark plugs - Replace | Every 40,000 miles or 6 years, whichever occurs first | S3, A3 e-tron®, TTS, A4, S4, A4 allroad®, A5, S5, A6 4-cylinder, A6 6-cylinder, A7, A8 Q5, Q5 e-tron®, SQ5, Q7 4-cylinder, Q8 | | | | |

2 8/27/2018



| Additional Maintenance Items | | | | | |
|--|---|--|--|--|--|
| Work to be completed | Interval | Model Application | | | |
| ☐ Spark plugs - Replace | Every 60,000 miles or 6 years, whichever occurs first | Q7 6-cylinder | | | |
| ☐ Spark plugs - Replace | Every 80,000 miles or 6 years, whichever occurs first | A3, A3 Cabriolet, TT, TT Roadster | | | |
| □ S-Tronic transmission - Change fluid | Every 40,000 miles | A3 e-tron®, RS 3, A4, A4 allroad®, A5 A6 4-cylinder, A6 6-cylinder, A7, Q5, Q5 e-tron® TT RS Coupe | | | |
| ☐ S-tronic transmission - Change fluid | Every 80,000 miles | A3, A3 Cabriolet, S3, TT, TT Roadster, TTS | | | |

MY 2019 Oil Capacity Chart

| Model | Engine | Engine oil Approx. qty. w/filter change | Audi Oil Spec* **See Engine Oil Type Chart on next page for specific viscosities |
|---------------|-----------|---|---|
| A3 B-cycle | 2.0L TFSI | 5.7L (6.0 qt) | 508* |
| RS 3 | 2.5L TFSI | 7.1L (7.5 qt) | 504* |
| S3 | 2.0L TFSI | 5.7L (6.0 qt) | 504* |
| A4/A4 allroad | 2.0L TFSI | 5.2L (5.49 qt) | 504* |
| A4 B-cycle | 2.0L TFSI | 5.2L (5.49 qt) | 508* |
| S4 | 3.0L TFSI | 7.25L (7.7 qt) | 508* |
| A5 | 2.0L TFSI | 5.2L (5.4 qt) | 504* |
| S5 | 3.0L TFSI | 7.25L (7.7 qt) | 508* |
| RS 5 | 2.9L TFSI | 7.6L (8.0 qt) | 504* |
| A6 | 2.0L TFSI | 5.2L (5.5 qt) | 508* |
| A6 | 3.0L TFSI | 7.6L (8.0 qt) | 508* |
| S6 | 2.9L TFSI | 7.6L (8.0 qt) | 504* |
| A7 | 3.0L TFSI | 7.6L (8.0 qt) | 508* |
| S7 | 2.9L TFSI | 7.6L (8.0 qt) | 504* |
| A8L | 3.0L TFSI | 7.6L (8.0 qt) | 508* |
| A8L | 4.0L TFSI | 9.5L (10.0 qt) | 504* |
| Q3 | 2.0L TFSI | 5.7L (6.0 qt) | 508* |
| Q5 | 2.0L TFSI | 5.2L (5.4 qt) | 508* |

3 8/27/2018



| Model | Engine | Engine oil Approx. qty. w/filter change | Audi Oil Spec* **See Engine Oil Type Chart on next page for specific viscosities |
|-------|-----------|--|---|
| SQ5 | 3.0L TFSI | 7.25L (7.7 qt) | 508* |
| Q7 | 2.0L TFSI | 5.2L (5.5 qt) | 504* |
| Q7 | 3.0L TFSI | 6.8L (7.2 qt) | 504* |
| Q8 | 3.0L TFSI | 7.6L (8.0 qt) | 508* |
| TT | 2.0L TFSI | 5.7L (6.0 qt) | 508* |
| TTS | 2.0L TFSI | 5.7L (6.0 qt) | 504* |
| TT RS | 2.5L TFSI | 7.1L (7.5 qt) | 504* |

**Engine Oil Types

(Edition 08.2017)

A CAUTION

All quantities are approximate. Always refer to the Repair Manual and/or the Maintenance Procedures for correct filling instructions.

Refer to Technical Bulletin 2010043 for engine oils meeting the required Audi oil quality standards.

Part numbers are for reference only. Always check with your parts department for the latest information.



Note:

Developed by Castrol®, in strategic co-operation with Volkswagen Group, the following Castrol® products meet VW/Audi specifications.

502 00 / 505 00 / 505 01

- Castrol EDGE® Professional® 5W40

508 00 / 509 00

Castrol EDGE® Professional® 0W20 Long Life IV

504 00 / 507 00 Diesel Oil

- Castrol EDGE® Professional® 5W30 LL03

501 01 / 505 00

- Castrol EDGE® Professional® 10W60 Super Car (Formerly Castrol EDGE® Professional TWS 10W60)

4

8/27/2018

^{© 2018} Audi of America, Inc.

[&]quot;All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Audi of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice.

No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher."