

HP 12c Platinum Financial Calculator Quick Start Guide



Edition 1

HP Part Number: F2232-90201

Legal Notices

This manual and any examples contained herein are provided "as is" and are subject to change without notice. Hewlett-Packard Company makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability, non-infringement and fitness for a particular purpose.

Hewlett-Packard Company shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples contained herein.

Copyright © 2008 Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation of this manual is prohibited without prior written permission of Hewlett-Packard Company, except as allowed under the copyright laws.

Hewlett-Packard Company
16399 West Bernardo Drive
San Diego, CA 92127-1899
USA

Printing History
Edition 1, October 2008

Table of Contents

| | |
|--|----|
| Welcome to your HP 12c Platinum Financial Calculator | 1 |
| The Keys..... | 1 |
| Customizing the Calculator | 2 |
| Storage Registers and Continuous Memory | 7 |
| Reverse Polish Notation (RPN) Mode..... | 7 |
| Keys and Functions | 10 |
| Basic Financial Calculation Example | 19 |
| Warranty and Contact Information | 21 |
| Replacing the Batteries | 21 |
| HP Limited Hardware Warranty and Customer Care | 22 |
| Limited Hardware Warranty Period | 22 |
| General Terms | 22 |
| Customer Care | 24 |
| Product Regulatory & Environment Information..... | 28 |

Contents

1 Getting Started

Welcome to your HP 12c Platinum Financial Calculator

This booklet is intended to get you started quickly with the basic features of your 12c Platinum Financial Calculator. Use it for quick reference. For more detailed information about the 12c Platinum, refer to the *HP 12c Platinum Financial Calculator User's Guide*. Pages of the user's guide are cited throughout this manual, and it is highly recommended you refer to the user's guide to thoroughly familiarize yourself with the many features of your calculator.

The Keys

Many keys on the HP12c Platinum perform more than one function. The primary function of a key is indicated by the characters printed in white on the upper face of the key. The alternate function(s) of a key are indicated by the characters printed in gold above the key and the characters printed in blue on the lower face of the key. See Figure 1.




Figure 1

- To specify the primary function printed on the upperface of a key, press the key alone.
- To specify the alternate function printed in gold above a key, press the gold prefix key (**f**), then press the function key.
- To specify the alternate function printed in blue on the lower face of a key, press the blue prefix key (**g**), then press the function key.

Pressing the **f** or **g** prefix key turns on the corresponding status indicator — **f** or **g** — in the display. After a function key is pressed, the indicator turns off. Note how function keys for bonds, depreciation, and clearing are grouped together under brackets printed above the keys in gold. Unless otherwise indicated, press and release the desired key, or key combination from left to right. You do not need to press and hold the keys as with a computer or typewriter.

There are a total of nine status indicators that appear along the bottom of the display and signify the status of the calculator for certain operations. When applicable, the descriptions below identify when an indicator appears on screen.

In this manual, the highlighted portion of the key symbol or symbols represents the active function of the key. Functions above the keys are spelled out and preceded by the **f** function key.

Customizing the Calculator

Table 1-1 lists some of the basic functions available for customizing the calculator. The pages of the *HP 12c Platinum Financial Calculator User's*

Guide are included for reference. Refer to these pages of the user's guide for more information.

Table 1-1 Basic Functions

| Functions | Display/Description |
|---|---|
| Turn calculator on/off (page 16). |  Turns calculator on. Pressing ON again turns the calculator off. The calculator turns off automatically 12 minutes after it was last used. |
| Operating mode (page 20). |  1. Press f ALG to set the operating mode to Algebraic mode. 2. Press f RPN to set the operating mode to Reverse Polish Notation (RPN) mode. 3. Note the "RPN" or "ALG" indicator. RPN is the default operating mode. |
| Display contrast (page 16). | Press and hold f while pressing + or - to adjust the display contrast, darker or lighter, respectively. |

Table 1-1 Basic Functions


| Functions | Display/Description |
|--|--|
| Digit separator (replace decimal point with a comma) (page 17). |  <p>The calculator display shows the number 123,456. Below the display, the letters "RPN" are visible, indicating the current operating system.</p> |
| Number display format (page 87). |  <p>The calculator display shows the number 1.12. Below the display, the letters "RPN" are visible, indicating the current operating system.</p> <p>Press and release f followed by a number 0-9 to specify the number of digits displayed to the right of the decimal point. The default setting is two places to the right of the decimal point.</p> |

Table 1-1 Basic Functions

| Functions | Display/Description |
|--|---|
| Calendar format. Month-day-year (M.DY) or Day-month-year (D.MY) (pages 37-40). | <p>Press [g] [5 M.DY] or [g] [4 D.MY] to set the date format. The default setting is M.DY. The screen above shows December 3, 2010 in M.DY format.</p> <ol style="list-style-type: none">1. Press [g] [5 M.DY].2. Key in one or two digits for the month.3. Press [.].4. Key in two digits for the day.5. Key in four digits for the year.6. Note: at this point, pressing [ENTER] displays the date in the selected number display format.   |

Table 1-1 Basic Functions

| Functions | Display/Description |
|------------------------------------|--|
| Compound interest (pages 63, 219). |  <p>Press STO <small>(</small> EEX <small>ADYS</small> followed by dates separated by ENTER = to specify the compound interest option for odd-period calculations of interest (i), Present Value (PV), Payment (PMT), and Future Value (FV). Note the "C" indicator appears. The default setting performs calculations for PV, PMT, and FV using simple interest. Press STO <small>(</small> EEX <small>ADYS</small> again to return to the default setting.</p> |
| Payment mode (page 46). |  <p>Press g 7 <small>BEG</small> to set the payment mode for cash flow problems. Use Begin mode for payments occurring at the beginning of the compounding period. Note the "BEGIN" indicator appears.</p> <p>Press g 8 <small>END</small> for payments occurring at the end of the compounding period. End mode is the default setting.</p> |

Storage Registers and Continuous Memory

Numbers (data) are stored in memories called “registers.” Special registers are used for storing numbers during calculations, the “stack” registers, and the “Last X” register, which is used for storing the last number in the display before operations are performed in RPN mode. Numbers are stored automatically in these registers. There are also registers in which you can manually store data, designated R_0 through R_9 , $R_{.0}$ through $R_{.9}$, and financial registers used for financial calculations. All these storage registers make up the calculator’s Continuous memory. All information in the Continuous memory is preserved even while the calculator is turned off. To reset the memory and clear all of the registers and return the calculator’s settings to their defaults, turn the calculator off, and while holding down , press . With “Pr Error” displayed, press any key to return to the default calculator screen.

Reverse Polish Notation (RPN) Mode

The following information is a brief overview of how RPN works. For more detailed information about RPN and how the stack works, refer to the *HP 12c Platinum Financial Calculator User’s Guide*. In RPN mode, numbers are entered first, separated by pressing , followed by an operation key. Pressing  is optional after entering a number, if the next key pressed is an operation.

Each time you press an operation or function key in RPN, the answer is calculated immediately and displayed. For example, suppose you wanted to add two numbers in RPN, 1 and 2. Press    .

The result, 3.00, is calculated and displayed immediately.

There are four special registers used for storing numbers during calculations, which are stacked on top of one another. Called “the stack,” these registers are designated *X*, *Y*, *Z*, and *T*. *X* is on the bottom, and *T* is on the top. Unless the calculator is in Program mode, the number in the display is the number in the *X*-register. Primarily, the numbers in the *X*- and *Y*-registers are the numbers used in calculations. The *Z* and *T* registers are used for the automatic retention of intermediate results during chain calculations.

The  key separates numbers in the vertical stack and positions them in the *X*- and *Y*-registers, and, in addition to displaying intermediate results, this vertical arrangement of the stack allows you to copy and rearrange numbers without reentering them. For more complex problems requiring two or more operations, you do not need to enter parentheses to set operational priority. Key in numbers and operations inside the parentheses first, followed by those outside of the parentheses. If a problem has more than one set of parentheses, start by working with the operations and numbers in the innermost parentheses and work out.

For example, in RPN mode calculate $(3 + 4) \times (5 + 6)$. See

Table 1-2. Although this is a simple example, you can use the principles introduced here when working with more complex problems.

Table 1-2 RPN Example

| Keys | Display/Description |
|---------------------|--|
| n! = D.MY LSTX |  RPN |
| M.DY = Z.W LSTX | Enters numbers and operation from the first set of parentheses. The sum, 7, is displayed and stored in the X-register. |
| X = r^2 |  RPN |
| | Enters the numbers and operation from the second set of parentheses. The sum, 11, is stored in the X-register and displayed, and 7 moves up to the Y-register. |
| |  RPN |
| | Finishes the operation and displays the results. Stores 77 in the X-register. |

Keys used to rearrange the stack:

- Pressing the  key exchanges the numbers in the X-and Y-registers (**pages 90, 230**).
- Pressing the  key performs a *roll down* of the stack, where each number in the registers is copied into the register below, and the number formerly in the X-register is copied into the T-register (**page 230**).
- Pressing  recalls the number displayed before the previous operation back into the displayed X-register (**pages 91, 234**).

In Algebraic mode, use parentheses to set operational priority. Press   to open and close parentheses (**pages 26, 240**).

Keys and Functions

Table 1-3 lists some of the keys used for basic operation, mathematical calculations, and financial problems. Use this table for quick reference. Page numbers from the *HP 12c Platinum Financial Calculator User's Guide* are included in the table for reference. Refer to the user's guide for a complete list of functions, including statistics and programming.

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|--|---|
|  Enter | Enters a copy of number in displayed X-register into Y-register. Used to separate numbers in RPN (pages 21, 229). |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|--------------------|--|
| | Arithmetic operators (pages 21, 22). |
| Change sign | Changes sign of number or exponent displayed in the X-register (page 17). |
| Parentheses | In Algebraic mode, parentheses are used to change the order in which operations are evaluated. When there are pending open parentheses, the "()" status indicator appears in the display (pages 26, 240). |
| Enter Exponent | For very large or very small numbers. Enter the mantissa. After pressing, , the next numbers keyed in are exponents of 10 (page 18). |
| | Backspace. Deletes the last character or a number (page 18). |
| Undo | Undo. Press with the "undo" arrow indicator lit (see down arrow in screen below) to "undo" the last operation and recover data. The undo indicator also appears when clearing the storage registers (page 20). |
| | |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|---|---|
| CLX <small>x=0</small> Clear | Clears contents of display and X-register to zero. After pressing, the undo indicator appears (see below). With this displayed, press g ÷ to recover data or CLX to clear (page 19). |
| |  |
| | Note: in Algebraic mode, begin calculations by pressing CLX CLV . This clears any pending arithmetic calculations. |
| f Σ Clear statistics | Clears statistics registers (R ₁ -R ₆), stack registers, and display. Note the “undo” indicator (see “undo” function above). With this displayed, press g ÷ to recover data, or CLX to clear (page 93). |
| f PRGM Clear program | Clears Program registers (page 104). |
| f FIN Clear financial | Clears financial registers. Note the “undo” indicator (see “undo” function above). With this displayed, press g ÷ to recover data, or CLX to clear (page 42). |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|--|--|
| f REG Clear all registers | Clears data storage registers, financial registers, stack (X,Y,Z, and T), LAST-X registers, and display. Note the “undo” indicator (see “undo” function above). With this displayed, press g  to recover data, or  x=0 to clear (page 29). |
| f PREFIX Cancel | After f , g ,  (, ) or  GTO , cancels that key (page 17). |
|  (Store | Press  and key in the register number (0-9 for registers R ₀ -R ₉ , or  0-9 for registers R _{.0} - R _{.9}) to store displayed number in a specified storage register. Also used to perform storage register arithmetic. (pages 27, 29). |
| ) Recall | To recall a number from a storage register into the display, press  , then key in the register number. This copies the number from the storage register into the display (page 27). |
|  % Percentage (in RPN) | Key in base number. Press  . Key in the percentage. Press  %. Calculates x% of y and retains the y value in the Y-register (pages 31, 241). |
|  % Percentage (in Algebraic) | Press f ALG . Key in base number. Press  . Key in percentage. Press  followed by  (pages 32, 241). |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|--|---|
|  | Key in the base numbers separated by  . Press  . Calculates percent change between number in Y-register and number displayed in X-register (page 34) . |
|  | Enter a total amount. Press  . Key in the number x whose percentage equivalent you wish to find. Press  . Calculates percent that x is of the number in Y-register (page 35) . |
|  | Calculates date and days from a starting date Key in start date and press  . Key in the number of days from entered date (if date is in the past, press ). Press  . Displays date and the day of the week as a number 1-7 to the right of the display: 1 is for Monday; 7 is for Sunday (page 38) . |
|  | Number of days between two dates Key in the earlier date and press  . Key in the later date and press  . Calculates the number of days between two dates in actual days. To display date based on a 30-day month, press  after completing steps listed above (page 40) . |
|  | Square root Calculates the square root of the number displayed in the X-register (page 100) . |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|--|--|
|  Power function | Raises the number in the Y-register to the power of the number in the X-register. In RPN, key in a number, x. Press  . Key in the exponent, followed by  . In Algebraic, enter a number, x. Press  . Key in the exponent followed by  (page 102). |
|  Reciprocal | Calculates the reciprocal of the number displayed in the X-register (page 100). |
|  Factorial | Calculates factorial of number displayed in the X-register (page 100). |
|  e^x | Natural antilogarithm. Raise e to power of the number displayed in the X-register (page 100). |
|  \ln | Calculates natural logarithm (base e) of the number in the displayed X-register (page 100). |
|  Square | Calculates square of the number displayed in the X-register (page 100). |
|  Round | Rounds mantissa of 10-digit number in X-register to match the display (page 100). |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|--------------------------------------|---|
| | Replaces the number in the display by its integer portion. It replaces each digit to the right of the decimal point by 0. In RPN, the original number can be recalled by pressing (page 101). |
| | Replaces the number in the display by its fractional portion. It replaces all digits to the left of the decimal point by 0. In RPN, the original number can be recalled by pressing (page 101). |
| | Calculates simple interest (page 42). |
| Simple interest | |
| | Stores or calculates number of periods in financial problems (pages 13, 41, 45). |
| Compounding periods | |
| | Multiplies a number in displayed X-register by 12 and stores the value in the i-register (page 49). |
| | Stores or computes interest rate per compounding period (pages 13, 41, 45). |
| Interest rate per compounding period | |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|---|---|
|   | Divides number in displayed X-register by 12 and stores the resulting value in the i-register (page 49). |
|   | Stores or calculates the present (the initial cash flow) value of a financial problem (page 41). |
| Present value | |
|   | Stores or calculates the payment amount (pages 41, 45). |
| Payment | |
|   | Stores or calculates the future value (final cash flow) of a financial problem (page 41, 46). |
| Future value | |
|  AMORT | Amortizes x number of periods using values stored in     and the display. Updates   and  |
| Amortization | (page 69). |
|  NPV | Calculates the net present value of up to 80 uneven cash flows and initial investment using stored values with     |
| Net Present Value | (page 72). |
|  IRR | Calculates the internal rate of return (yield) for up to 80 uneven cash flows and initial investment using values stored in     |
| Internal Rate of Return | (pages 72, 78). |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|--|---|
| g   | Initial cash flow. Stores contents of displayed X-register in R_0 , initializes n to zero, sets N_0 to 1. Used at the beginning of a discounted cash flow problem (pages 45, 73). |
| g   | Cash flow j. Stores the contents of X-register in R_1 , increments n by 1, and sets N_1 to 1. Used for all cash flows except the initial cash flow in a discounted cash flow problem (pages 45, 73). |
| f  SL Depreciation | Calculates depreciation using straight-line method (page 84). |
| f  PRICE Bond price | Calculates bond price, given desired yield to maturity (page 82). |
| f  YTM Bond yield | Calculates yield to maturity, given bond price (page 83). |
| g   | Stores the number of times (from 1 to 99) each cash flow occurs as N_j . Assumes 1 unless otherwise specified (page 75). |
| f  SOYD Depreciation | Calculates depreciation using the sum-of-the-years-digits method (page 84). |

Table 1-3 Keys and Functions

| Key(s) | Description and Page Number in the User's Guide |
|-----------------------------|--|
| f DB Depreciation | Calculates depreciation using the declining-balance method (page 84). |



Basic Financial Calculation Example

Table 1-4 illustrates how easily you can perform financial calculations using the HP 12c Platinum Financial Calculator. The example calculates the monthly payment amount on a 30-year loan of 125,000.00 with a 6.9% annual interest rate, compounded monthly. It assumes payments occur at the end of the compounding period. The example is calculated using the default settings in RPN unless otherwise indicated.

For more examples and information on financial problems, including cash flows and using cash flow diagrams, refer to section three of the *HP 12c Platinum Financial Calculator User's Guide*.

Table 1-4 Loan Payment Example

| Keys | Display/Description |
|--------------|--|
| f FIN |  Clears financial registers. Press CLx to return to the default screen. |

| Keys | Display/Description |
|---|---|
|  |  Sets payment mode to End. |
|  |  Enters the annual interest rate in terms of the basic compounding period (6.9% divided by 12 months per year). |
|  |  Enters the number of monthly compounding periods (n) for a 30-year loan (12 payments per year x 30). |
|  |  Enters the present value of the loan. |

| Keys | Display/Description |
|---|--|
|  |  |
| | Enters the future value of the loan after it has been paid off (0.00). |
|  |  |
| | Calculates monthly payment amount. Note the sign is negative; it is money you pay out. |

Warranty and Contact Information

Replacing the Batteries

The calculator uses two, 3 Volt CR2032 Lithium batteries. The battery symbol (■) appears in the display when battery power is running low. Use only fresh batteries when replacing the batteries. Do not use rechargeable batteries. To install new batteries:

1. With the calculator turned off, slide the back cover off.
2. Remove only one battery at a time. Remove one of the old batteries and replace it with a new battery with the positive polarity symbol facing outward.
3. Remove the other old battery and replace it with a new battery with the positive polarity symbol facing outward.
4. Replace the back cover.

Warning! There is danger of explosion if the battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. Do not mutilate, puncture, or dispose of batteries in fire. The batteries can burst or explode, releasing hazardous chemicals.

HP Limited Hardware Warranty and Customer Care

This HP Limited Warranty gives you, the end-user customer, express limited warranty rights from HP, the manufacturer. Please refer to HP's Web site for an extensive description of your limited warranty entitlements. In addition, you may also have other legal rights under applicable local law or special written agreement with HP.

Limited Hardware Warranty Period

Duration: 12 months total (may vary by region, please visit www.hp.com/support for latest information)

General Terms

HP warrants to you, the end-user customer, that HP hardware, accessories and supplies will be free from defects in materials and workmanship after the date of purchase, for the period specified above. If HP receives notice of such defects during the warranty period, HP will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or like-new.

HP warrants to you that HP software will not fail to execute its programming instructions after the date of purchase, for the period specified above, due to defects in material and workmanship when properly installed and used. If HP receives notice of such defects during the warranty period, HP will replace software media which does not execute its programming instructions due to such defects.

HP does not warrant that the operation of HP products will be uninterrupted or error free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a refund of the purchase price upon prompt return of the product with proof of purchase.

HP products may contain remanufactured parts equivalent to new in performance

or may have been subject to incidental use.

Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by HP, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

HP MAKES NO OTHER EXPRESS WARRANTY OR CONDITION WHETHER WRITTEN OR ORAL. TO THE EXTENT ALLOWED BY LOCAL LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY SET FORTH ABOVE. Some countries, states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This warranty gives you specific legal rights and you might also have other rights that vary from country to country, state to state, or province to province.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some countries, States or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. HP shall not be liable for technical or editorial errors or omissions contained herein.

FOR CONSUMER TRANSACTIONS IN AUSTRALIA AND NEW ZEALAND: THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Customer Care

In addition to the one year hardware warranty your HP calculator also comes with one year of technical support. If you need assistance, HP customer care can be reached by either email or telephone. Before calling please locate the call center nearest you from the list below. Have your proof of purchase and calculator serial number ready when you call.

Telephone numbers are subject to change, and local and national telephone rates may apply. For more support information, please visit the web at: www.hp.com/support.

Table 1-5 Customer Care

| Country | Hotline Phone | Country | Hotline Phone |
|----------------|---|---------------------------|---|
| Algeria | www.hp.com/ support | Anguila | 1-800-711-2884 |
| Antigua | 1-800-711-2884 | Argentina | 0-800-555-5000 |
| Aruba | 800-8000 ; 800- 711-2884 | Australia | 1300-551-664 or 03-9841-5211 |
| Austria | 01 360 277 1203 | Bahamas | 1-800-711-2884 |
| Barbados | 1-800-711-2884 | Belgium | 02 620 00 86 |
| Belgium | 02 620 00 85 | Bermuda | 1-800-711-2884 |
| Bolivia | 800-100-193 | Botswana | www.hp.com/ support |
| Brazil | 0-800-709-7751 | British Virgin Islands | 1-800-711-2884 |
| Bulgaria | www.hp.com/ support | Canada | 800-HP-INVENT |

| Country | Hotline Phone | Country | Hotline Phone |
|--------------------|---|-----------------|--|
| Cayman Island | 1-800-711-2884 | Chile | 800-360-999 |
| China | 010-58301327 | Columbia | 01-8000-51-4746-8368 (01-8000-51-HP INVENT) |
| Costa Rica | 0-800-011-0524 | Croatia | www.hp.com/ support |
| Curacao | 001-800-872-2881 + 800-711-2884 | Czech Republic | 296 335 612 |
| Denmark | 82 33 28 44 | Dominica | 1-800-711-2884 |
| Dominican Republic | 1-800-711-2884 | Ecuador | 1-999-119 ; 800-711-2884 (Andinatel) 1-800-225-528; 800-711-2884 (Pacificitel) |
| Egypt | www.hp.com/ support | El Salvador | 800-6160 |
| Estonia | www.hp.com/ support | Finland | 09 8171 0281 |
| France | 01 4993 9006 | French Antilles | 0-800-990-011; 800-711-2884 |
| French Guiana | 0-800-990-011; 800-711-2884 | Germany | 069 9530 7103 |

| Country | Hotline Phone | Country | Hotline Phone |
|----------------|---|----------------|---|
| Ghana | www.hp.com/ support | Greece | 210 969 6421 |
| Grenada | 1-800-711-2884 | Guadelupe | 0-800-990-011; 800-711-2884 |
| Guatemala | 1-800-999-5105 | Guyana | 159 ; 800-711- 2884 |
| Haiti | 183 ; 800-711- 2884 | Honduras | 800-0-123 ; 800- 711-2884 |
| Hong Kong | 852 2833-1111 | Hungary | www.hp.com/ support |
| Indonesia | +65 6100 6682 | Ireland | 01 605 0356 |
| Italy | 02 754 19 782 | Jamaica | 1-800-711-2884 |
| Japan | 81-3-6666-9925 | Kazakhstan | www.hp.com/ support |
| Latvia | www.hp.com/ support | Lebanon | www.hp.com/ support |
| Lithuania | www.hp.com/ support | Luxembourg | 2730 2146 |
| Malaysia | +65 6100 6682 | Martinica | 0-800-990-011; 877-219-8671 |
| Mauritius | www.hp.com/ support | Mexico | 01-800-474- 68368 (800 HP INVENT) |

| Country | Hotline Phone | Country | Hotline Phone |
|------------------------|---|----------------|---|
| Montenegro | www.hp.com/ support | Montserrat | 1-800-711-2884 |
| Morocco | www.hp.com/ support | Namibia | www.hp.com/ support |
| Netherland Antilles | 001-800-872-2881 ; 800-711-2884 | Netherlands | 020 654 5301 |
| New Zealand | 0800-551-664 | Nicaragua | 1-800-0164; 800- 711-2884 |
| Norway | 23500027 | Panama | 001-800-711-2884 |
| Paraguay | (009) 800-541- 0006 | Peru | 0-800-10111 |
| Philippines | +65 6100 6682 | Poland | www.hp.com/ support |
| Portugal | 021 318 0093 | Puerto Rico | 1-877 232 0589 |
| Romania | www.hp.com/ support | Russia | 495 228 3050 |
| Saudi Arabia | www.hp.com/ support | Serbia | www.hp.com/ support |
| Singapore | +65 6100 6682 | Slovakia | www.hp.com/ support |
| South Africa | 0800980410 | South Korea | 2-561-2700 |

| Country | Hotline Phone | Country | Hotline Phone |
|------------------|---|-------------------|---|
| Spain | 913753382 | St Vincent | 01-800-711-2884 |
| St Kitts & Nevis | 1-800-711-2884 | St Lucia | 1-800-478-4602 |
| St Marteen | 1-800-711-2884 | Suriname | 156 ; 800-711-2884 |
| Swaziland | www.hp.com/ support | Sweden | 08 5199 2065 |
| Switzerland | 022 827 8780 | Switzerland | 01 439 5358 |
| Switzerland | 022 567 5308 | Taiwan | +852 2805-2563 |
| Thailand | +65 6100 6682 | Trinidad & Tobago | 1-800-711-2884 |
| Tunisia | www.hp.com/ support | Turks & Caicos | 01-800-711-2884 |
| UAE | www.hp.com/ support | United Kingdom | 0207 458 0161 |
| Uruguay | 0004-054-177 | US Virgin Islands | 1-800-711-2884 |
| USA | 800-HP INVENT | Venezuela | 0-800-474-68368 (0-800 HP INVENT) |
| Vietnam | +65 6100 6682 | Zambia | www.hp.com/ support |

Product Regulatory & Environment Information

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B

digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hewlett-Packard Company may void the user's authority to operate the equipment.

Declaration of Conformity for products Marked with FCC Logo, United States Only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. If you have questions about the product that are not related to this declaration, write to:

Hewlett-Packard Company
P.O. Box 692000, Mail Stop 530113
Houston, TX 77269-2000

For questions regarding this FCC declaration, write to:

Hewlett-Packard Company
P.O. Box 692000, Mail Stop 510101
Houston, TX 77269-2000
or call HP at 281-514-3333

To identify your product, refer to the part, series, or model number located on the product.

Canadian Notice

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Avis Canadien


Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

European Union Regulatory Notice

This product complies with the following EU Directives:

- Low Voltage Directive 2006/95/EC
- EMC Directive 2004/108/EC
- Compliance with these directives implies conformity to applicable harmonized European standards (European Norms) which are listed on the EU Declaration of Conformity issued by Hewlett-Packard for this product or product family.

This compliance is indicated by the following conformity marking placed on the product:



This marking is valid for non-Telecom products and EU harmonized Telecom products (e.g. Bluetooth).

This marking is valid for EU non-harmonized Telecom products. *Notified body number (used only if applicable-refer to the product label).

Hewlett-Packard GmbH, HQ-TRE, Herrenberger Strasse 140, 71034 Boeblingen, Germany

Japanese Notice

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

Korean Notice

B급 기기
(가정용 방송통신기기)

이 기기는 가정용(B급)으로 전자파적합등록을 한 기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

Disposal of Waste Equipment by Users in Private Household in the European Union



This symbol on the product or on its packaging indicates that this product just not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Chemical Substances

HP is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements such as REACH (*Regulation EC No 1907/2006 of the European Parliament and the Council*). A chemical information report for this product can be found at:

<http://www.hp.com/go/reach>

Perchlorate Material - special handling may apply

This calculator's Memory Backup battery may contain perchlorate and may require special handling when recycled or disposed in California.

| 产品中有毒有害物质或元素的名称及含量 根据中国《电子信息产品污染控制管理办法》 | | | | | | |
|--|-----------|--------|--------|--------------|------------|--------------|
| 部件名称 | 有毒有害物质或元素 | | | | | |
| | 铅 (Pb) | 汞 (Hg) | 镉 (Cd) | 六价铬 (Cr(VI)) | 多溴联苯 (PBB) | 多溴二苯醚 (PBDE) |
| PCA | X | 0 | 0 | 0 | 0 | 0 |
| 外包装 /字迹 | 0 | 0 | 0 | 0 | 0 | 0 |

O : 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006 标准规定的限量要求以下。

X : 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。

表中标有“X”的所有部件都符合欧盟RoHS法规

欧洲议会和欧盟理事会2003年1月27日关于电子电器设备中限制使用某些有害物质的2002/95/EC号指令

注：环保使用期限的参考标识取决于产品正常工作的温度和湿度等条件