

## Installing the Update DVD

### To remove old DVD:

1. To avoid carbon monoxide poisoning, start the vehicle outside in a well ventilated area.
2. Locate the navigation control unit. It may be installed in the trunk, the console compartment, below the transmission shift lever, or under the driver's or passenger's seat. Consult the owner's manual if necessary.
3. Open the access door by pushing the OPEN button.
4. Push the EJECT button. The DVD will automatically eject halfway out of the unit.
5. Pull the DVD straight out.
6. If the version of your original DVD label shows: Ver. 4.09, Ver. 4.11, Ver. 4.12, Ver. 4.13 (A, B, C, O) or Ver. 4.20 (A, B), proceed to the instructions for running the setup disc prior to loading your new Update DVD.

*\* If the version of your original DVD label is Ver. 4.31 or greater, proceed to the loading instructions for installing the new Update DVD.*

### To run setup disc:

1. With the label facing up, insert the setup disc labeled: "Honda / Acura NAVIGATION UPDATE SETUP DISC" into the DVD slot. The setup disc is automatically pulled into the control unit.
2. After the setup disc loads, close the control unit door. It will take about a minute for the software to update. The update progress will be displayed on the navigation screen. The system will automatically

restart after the software is updated. The system will display the disclaimer screen without showing the OK button - this is normal.

3. Eject the setup disc labeled "Honda / Acura NAVIGATION UPDATE SETUP DISC."

### To install new Update DVD:

1. Make sure the label is facing up. Slide the new update DVD into the slot. The DVD is automatically pulled into the control unit.
2. After the DVD loads, close the control unit door.
3. It will take about a minute for the navigation system to update. The update progress is displayed on the navigation screen.
4. The system will automatically restart after the update process is completed.
5. Before calculating a route with the new software, the vehicle must be driven on a verified road. As soon as the current road name appears on the bottom of the screen, the system is ready for use.

