Techstream Lite Kit Installation Instructions for MongoosePro MFC/MFC2 Vehicle Interface Modules (VIM)

Table of Contents

https://techinfo.toyota.com

Installing MongoosePro MFC/MFC2 Software from Techinfo Website

Required to proceed:

- PC with Windows 10 (32-bit or 64 bit)
- PC with Internet Explorer 11, Google Chrome, or Firefox 21.0 or later version
- PC configured for access to the Internet

Perform the following:

1. Go to https://techinfo.toyota.com, enter **User Name** and **Password** then click **Login**.

https://techinfo.toyota.com

TS Lite PRO Kit Installation Instructions – Rev 3.4

2. Click on **TIS → Diagnostics → ScanTool**

32 and 64-bit versions of the MongoosePro MFC and MFC2 software can be found in the Techstream Lite section. Select the applicable software link to download the installation file.

NOTE: The MongoosePro MFC/MFC2 software versions shown are for reference, as updated versions may be available.

https://techinfo.toyota.com

TS Lite PRO Kit Installation Instructions – Rev 3.4

3. From the Downloads folder on your PC, double click on the downloaded installation file.

   NOTE: MongooseProMFC2_x64 shown as an example. Your content may differ depending on the downloaded version.

4. A setup screen will appear as shown. Check the box labeled "**I accept the terms in the License Agreement**" then click **Install**.

   NOTE: MongoosePro MFC2 installation screen shown as an example. MongoosePro MFC installation screen differs but follows the same setup procedure.

5. You will be instructed to attach the MongoosePro MFC/MFC2 device to the computer *after* the installation is complete. Click **OK**.

    NOTE: MongoosePro MFC2 installation screen shown as an example. MongoosePro MFC installation screen differs but follows the same setup procedure.

6. Click **Finish** to exit the setup

   **NOTE:** MongoosePro MFC2 installation screen shown as an example. MongoosePro MFC installation screen differs but follows the same setup procedure.

7. Connect the **MongoosePro MFC/MFC2** VIM to the PC USB port. The Mongoose driver will be installed automatically. After a few minutes, confirm the green LED light in the DLC3 (OBD-II) end of the VIM is flashing. This indicates the driver is installed and MongoosePro MFC/MFC 2 VIM is ready to be used.

Installing Techstream Software from Techinfo Website

Perform the following:

1. Go to https://techinfo.toyota.com, enter **User Name** and **Password** then click **Login**.


2. Click on **TIS → Diagnostics → ScanTool**

   In the Techstream Software section, select **Full Install** to download the installation file.

   NOTE: The Techstream software version shown is for reference, as an updated version may be available.

TS Lite PRO Kit Installation Instructions – Rev 3.4

3. From the Downloads folder on your PC, double click on the downloaded installation file.

   NOTE: Techstream_SetupNA_V14.20.019 shown as an example. Your content may differ depending on the available version.

4. Choose setup language and click **Next** to continue.

5. Click **Next** again to continue.

https://techinfo.toyota.com

TS Lite PRO Kit Installation Instructions – Rev 3.4

6. Check the box labeled "**I accept the terms of the License Agreement**" then click **Next**.

7. Enter your **User Name** and **Company Name**, then click **Next** to continue.

8. Click **Install** to begin the installation.

9. Click **Finish** to complete the installation

Configuring Techstream Software for Your PC

Perform the following:

1. From your Windows Desktop, double click the Techstream icon.

2. Select **North America** and click **Next** to continue.

3. Select a Language from the drop-down option. English is default. Click **Next.**

4. Enter the Shop Name, Shop Code and Phone Number, then select the appropriate Country/Region and **Public User** for the User Type. Click **OK** to continue.

Registering Techstream Software

Techstream Software requires registration with the Techinfo site before it can connect to a vehicle. Techinfo registration is limited to only one PC per Techinfo subscription. The Techstream registration will be good for the duration of the Techinfo subscription.

Perform the following:

1. From Techstream main screen, click **Software Registration.**

2. Click the **Software Registration** button.

3. Log into https://techinfo.toyota.com by entering your **User Name** and **Password** then click **Login**.

TS Lite PRO Kit Installation Instructions – Rev 3.4

4. Enter a Computer Name and a Shop/Owner Name, then click **Calculate Key.**

Techstream Software Registration

Thank you for registering your Techstream Software.

Please enter the required information below and click "Calculate Key" to complete the Techstream Software Registration Process.

User ID:	**gutieca**
*Software ID:	EC252B7C118AFE4AE567A49E547CFFB0
*Software Version:	14.20.019
Computer Name⁺:	Computer 1 (five (5) character minimum)
Shop/Owner Name⁺:	Shop Name (five (5) character minimum)

Calculate Key

Key: [   ]
1. Highlight the key by double clicking on it
2. Right click on the key and select "copy"
3. Paste the key into the Techstream software by right clicking on the "key" box and selecting "paste"
4. Press "OK" to finish registration

5. Copy the Key from the Techinfo website.

Calculate Key

Key: a0b3a092dc6432b902a224df93d1e69d00771311040946
1. Highlight the key by double clicking on it
2. Right click on the key and select "copy"
3. Paste the key into the Techstream software by right clicking on the "key" box and selecting "paste"
4. Press "OK" to finish registration

1. Double click to highlight the entire key
2. Press Ctrl + C from the keyboard to copy

6. Return to the Register Techstream Software screen and paste the Key in the New Key field. Click **OK** to register.

Register Techstream Software (S314-01)

Registration information:

Software ID:	EC252B7C118AFE4AE567A49E547CFFB0
Software Version:	14.20.019
Current Key:	
New Key:	dc6432b902a224df93d1e69d00771311040946

To register software, click on the Software Registration button below. If you are unable to access the software registration web page, contact Techstream support. For Techstream support, click the Support Information button below. **1. Place the cursor in the key box**
2. Press Ctrl + V from the keyboard to paste
3.
Software Registration   Support Information

OK   Evaluate   Cancel

Note: The Register Techstream Software screen will close and the Techstream software is now registered.

https://techinfo.toyota.com

TS Lite PRO Kit Installation Instructions – Rev 3.4

Selecting the MongoosePro MFC/MFC2 VIM from Techstream

Techstream software requires a VIM selection before you can use the MongoosePro MFC/MFC2 VIM. Perform the following steps to select the appropriate VIM.

Perform the following:

1. Select **Setup** from the Techstream Main Menu
2. Select **VIM Select** from the **Setup** drop-down menu

3. Click the Interface setup drop-down arrow and select the appropriate VIM from the list, then click **OK**.

   NOTE: MongoosePro MFC/MFC2 software must be installed before your VIM selection will be available. MongoosePro MFC2 selection shown as an example.

Connecting to Vehicle to Verify Techstream Lite Operation

Perform the following:

1. Connect **MongoosePro MFC/MFC2** device to PC via USB port.

2. Connect **MongoosePro MFC/MFC2** device to vehicle's **DLC3 (OBD-II)** port.

3. From the Techstream main menu, click **Connect to Vehicle.**

4. Vehicle information should be prepopulated as in the example below. Select the appropriate vehicle **Option** and click **Next**.

5. From the **System Selection Menu**, select an ECU and click on the **Green Arrow** to confirm communication with the ECU. If Techstream advances to the Trouble Codes screen, communication has been established and you are done!

Techstream Lite Technical Support Information

Technical support: **1-877-762-7666**

Email support: **Techinfo@Toyota.com**

https://techinfo.toyota.com