ADVANCED PLOTTING DEVICES, INC.

Install APD Flashfirmware and USB Drivers For Windows XP, Windows Vista and Windows 7

A – Install APD Flashfirmware and Drivers Setup Software	page 1
B – Install USB Drivers for APD/ANAGraph Plotter	
for Windows XP, Windows Vista and Windows 7	page 5
C – Install Microsoft Forms 2.01	page 7

A. Install APD Flashfirmware and Drivers Setup Software:

- Run "APD FlashFirmware and Drivers Setup.msi" to install Flashfirmware and Drivers Setup software.
- Click "Next" to continue:

🖞 APD - FlashFirmware and Drivers
Welcome to the APD - FlashFirmware and Drivers Setup Wizard
The installer will guide you through the steps required to install APD - FlashFirmware and Drivers on your computer.
Click "Next" to continue.
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the law.
Cancel Previous Next

- 2 -

Click "Next":



Click "Next":





➢ Click "Close" to finish:

🙀 APD - FlashFirmware and Drive	ers		
Installation Complete			
APD - FlashFirmware and Drivers has b	een sucessfully ins	stalled.	
Click "Close" to exit.			
	<u>C</u> ancel	Previous	

> And then click on **Start** menu, you will see the installed program as follows:



Click on Start menu, select "APD – Flashfirmware" and then click on "Install APD USB Drivers":



> The setup wizard will be showed as follows:



> This panel will be showed when APD USB Drivers is installed successful:



- And now you can plug APD/ANAGraph plotter into your computer via USB port. The computer will search drivers for it automatically.
- ➤ Finished!

C. Install Microsoft Forms 2.01:

Once APD – Flashfirmware was installed successful. But you can not run "APD – Flashfirmware" when you click on Start menu.

In this case, you must install Microsoft Forms 2.01 as follows:

Click on Start menu, select "APD – Flashfirmware" and then click on "Install Microsoft Forms 2.01":



Click "Yes" to continue:



> Click "Yes":

Microso END-U SOFTV	oft Forms 2.01 SER LICENSE AG VARE	GREEMENT FOR M	ICROSOFT	- m
IMPOR Agreem individu Microso comput materia PRODI use cop	TANT-READ CAP bent ("EULA") is a ball or a single entit off software accorn er software and m ls, and "online" or JCT" or "SOFTW bies of the SOFTV his of this EULA. If	REFULLY: This Micr legal agreement bet ty) and Microsoft Cor npanying this EULA, nay include associate r electronic documer (ARE"). By exercising WARE PRODUCT, y f you do not agree to	osoft End-User License tween you (either an poration for the which includes ad media, printed ttation ("SOFTWARE g your rights to make and ou agree to be bound by the terms of this EULA,	l

Click **"OK"** to finish:

