

QUICK REFERENCE GUIDE



TACOMA

2023

2023

TACOMA

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new Tacoma.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of Tacoma operations. Every Tacoma owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW

Engine maintenance	9
Fuel tank door release and cap	8
Hood release	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Instrument panel light control	8
Keyless entry ^{1,2}	6
Smart Key system ^{1,2}	7

FEATURES & OPERATIONS

Active traction control	26
Air conditioning/heating	23
Audio	18
Auto lock/unlock ^{1,2}	20
AUTO LSD system	26
Automatic transmission	10
Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA)	28
Clock	24
Clutch start cancel switch	12
Crawl Control	12
Door lock switches	24
Four-wheel drive	11
Front seats-Adjustments	14
Garage door opener (HomeLink®) ³	18
Heated seats	24
Intuitive parking assist ^{1,2}	29
Lights ^{1,2} & turn signals	16-17
Manual transmission	11
Moonroof	22
Multi-Information Display (MID) ^{1,2}	22
Multi-Terrain Select	13
Parking brake	11
Power outlet-12V DC	25
Power outlet-120V AC	25
Power Sliding Rear window	21
Power windows	17
Qi Wireless charger	21
Rear differential lock	27

FEATURES & OPERATIONS (continued)

Rear seats-Folding	15
Rear view monitor system	29
Seats-Head restraints	14
Steering lock release	28
Steering wheel switches & telephone controls (Bluetooth®)	19
Tilt and telescopic steering wheel	13
Trailer lights	25
USB charge ports	20
USB media port	20
Vehicle Stability Control (VSC)/TRAC/ Trailer sway control OFF switch	27
Windshield wipers & washers	17

TOYOTA SAFETY SENSE™ P (TSS-P)

Automatic High Beams (AHB)	40
Dynamic Radar Cruise Control (DRCC)	37-39
Lane Departure Alert (LDA)	33-36
Pre-Collision System with Pedestrian Detection (PCS w/PD)	31-33
Quick overview- Toyota Safety Sense™ P (TSS-P)	30
Sensors	30

SAFETY & EMERGENCY FEATURES

Floor mat installation	45
Rear door child safety locks	42
Safety Connect®	41
Seat belts	41
Seat belts-Shoulder belt anchor	41
Spare tire & tools	43
Star Safety System™	44-45
Tire Pressure Monitoring (warning) System (TPMS)	42

GETTING STARTED WITH TOYOTA AUDIO MULTIMEDIA AND CONNECTED SERVICES



46-59

¹ Visit your Toyota dealer for information on customizing this feature.

² Programmable by customer. Refer to the "Owner's Manual" for instructions and more information.

³ HomeLink® is a registered trademark of Gentex Corporation.

Instrument panel




¹ If equipped.

² Manual transmission only.


³ Automatic transmission only.

⁴ For details, refer to the "Navigation and Multimedia System Owner's Manual" or visit www.toyota.com/audio-multimedia for additional resources.



OVERVIEW

Instrument cluster













































○ Service indicators and warning lights

* Available only on vehicles with automatic transmissions

Indicator symbols

For details, refer to "Warning lights and indicators," Section 2, 2023 "Owner's Manual".

 A-TRAC Active traction control system indicator ⁵	 BSM (Blind Spot Monitor) outside rear view mirror indicators ⁵
 AIR BAG ON/OFF indicators ¹	 Brake Override System/Drive-Start Control warning
 ABS  ABS (Anti-lock Brake System) warning ¹	 BRAKE  Brake system warning ¹
 AUTO LSD AUTO LSD (Limited Slip Differential) indicator ¹	 Charging system warning
 AUTO AHB (Automatic High Beams) indicator	  Constant speed cruise control/ Dynamic Radar Cruise Control (DRCC) indicator
 A/T OIL TEMP Automatic transmission fluid temperature warning	 SET Constant speed cruise control/ Dynamic Radar Cruise Control (DRCC) SET indicator
	 Crawl control indicator ⁵

	Driver and/or front passenger seat belt reminder ⁶ (alarm will sound when the vehicle is on)		Malfunction/Check Engine indicator ¹
	Fog light indicator ⁵		Master warning ^{1,2,6}
	Four-wheel drive indicator (4WD models)		Multi-terrain select indicator ⁵
	Fuel tank door position		Parking brake indicator ⁶
	Headlight low/high beam indicators		Power mode indicator (Automatic transmission only)
	High coolant temperature warning		PCS (Pre-Collision System) warning ^{1,2,6}
	LDA (Lane Departure Alert) indicator [green/yellow ⁴ indicator]		Rear differential lock indicator ^{1,3,5}
	Low engine oil level warning		Security indicator ⁵
	Low engine oil pressure warning		Slip indicator ^{1,4}
	Low fuel level warning		SRS airbag warning ¹
	Low outside temperature indicator		Traction control OFF indicator ¹
	Low speed four-wheel drive indicator (4WD models) ²		Turn signal indicator
	Low tire pressure warning ¹		VSC (Vehicle Stability Control) OFF indicator ¹

¹ If the indicator does not turn off within a few seconds of starting the engine, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.

² If the indicator flashes, there may be a malfunction. Refer to the "Owner's Manual".

³ If the indicator flashes rapidly, there may be a malfunction. Refer to the "Owner's Manual".

⁴ If the indicator flashes, it indicates that the system is operating.


⁵ If equipped.

⁶ With buzzer sound.

OVERVIEW

Keyless entry (if equipped)

UNLOCKING OPERATION



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

LOCKING OPERATION



PANIC BUTTON




* Pressing the button again within 3 seconds unlocks the other doors.

Please refer to the "Owner's Manual" for more details.

NOTE: Vehicle equipped with a Smart Key system - Doors may also be locked/unlocked using the mechanical key. (Press the release button on the side of Smart Key and take the mechanical key out.)

Smart Key system (if equipped)


START FUNCTION



NOTE: The Smart Key must be carried to enable the start function. With the shift lever in Park and the brake pedal depressed, press the power button.


POWER (WITHOUT STARTING VEHICLE)

Without depressing the brake pedal, pressing the power button will change the operation mode in succession from:




OVERVIEW

Fuel tank door release and cap




NOTE: Tighten until one click is heard. If the cap is not locked or tightened enough, the Check Engine indicator  may illuminate.

Hood release




Instrument panel light control




Engine maintenance

4 CYLINDER (2TR-FE) ENGINE




6 CYLINDER (2GR-FKS) ENGINE



NOTE: Regularly scheduled maintenance at your Toyota dealer, including oil changes, will help extend the life of your vehicle and maintain performance.


Please refer to the "Warranty & Maintenance Guide."

Automatic transmission (if equipped)



* The vehicle must be on and the brake pedal depressed to shift from Park.

"S" MODE



The initial shift range in "S" mode is set automatically to 5 or 4 according to vehicle speed.


Selecting shift ranges using "S" mode restricts the upper limit of the possible gear ranges, controls engine braking forces and prevents unnecessary upshifting.

Shift the shift lever to "S" position from "D" position.

- + : Upshift (push and release)
- : Downshift (pull and release)

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.


POWER MODE




Use when high levels of response and feeling are desirable, such as when driving in mountainous regions or when pulling a trailer.

Refer to the "Owner's Manual" for more information.

Manual transmission (if equipped)



Four-wheel drive (if equipped)



2WD **High speed (2WD)** Normal driving on dry hard-surfaced roads.

4H **High speed (4WD)**
For driving only on roads that permit the tires to slide, like off-road, icy or snow-covered roads.


4L **Low speed (4WD)**
For maximum power and traction when climbing or descending steep hills, off-road driving, and hard pulling in sand, mud or deep snow.

NOTE: For best fuel economy and performance under normal driving conditions, keep in “2WD” position.


Refer to the “Owner’s Manual” for more information.

Parking brake

Set




Release



PARK

Clutch start cancel switch (if equipped)




The vehicle must be in the "ON" position.

The clutch start cancel switch allows you to start the engine and drive out of difficult situations where the vehicle should not be allowed to roll backwards.

Refer to the "Owner's Manual" for more information.

Crawl Control (if equipped)




Crawl Control allows travel on extremely rough off-road surfaces at a fixed low speed without pressing the accelerator or brake pedal. Minimizes loss of traction or vehicle slip when driving on slippery road surfaces, allowing for stable driving.

- (1) Low to (2) Between low and medium** - Rock, mogul (downhill) and gravel (downhill)
- (2) Between low and medium to (3) Medium** - Mogul (uphill)
- (3) Medium to (5) High** - Snow, mud, gravel (uphill), sand, dirt, mogul (uphill) and grass

Refer to the "Owner's Manual" for more information.






Multi-Terrain Select (if equipped)



Multi-Terrain Select (MTS) is a system that improves driveability in off-road situations. Select one of five modes that most closely matches the terrain on which you are driving. Brake control can be optimized in accordance with the selected mode.


MTS can be operated when the four-wheel drive control switch is in “4L” position and The Crawl Control is off.

5 modes

- | | | |
|---|--|---|
| (1)  Mud & Sand | (2)  Loose Rock | (3)  Mogul |
| (4)  Rock & Dirt | (5)  Rock | |

Refer to the “Owner’s Manual” for more information.

Tilt and telescopic steering wheel



Hold the steering wheel, push the lever down, set angle and length, and return the lever.

NOTE: Do not attempt to adjust while the vehicle is in motion.


FEATURES & OPERATIONS

Seats-Head restraints

ACCESS CAB MODELS

Separate seats-Front


Vertical adjustment



Lock release button

Separate-Rear

Folding




Lock release lever

DOUBLE CAB MODELS

Separate seats-Front


Vertical adjustment



Lock release button

Center-Rear


Vertical adjustment



Lock release button

Outer-Rear


Folding




Lock release button

Front seats-Adjustments

MANUAL SEAT




POWER SEAT* (DRIVER'S SIDE ONLY)




*If equipped.

Rear seats-Folding

RAISING - ACCESS CAB MODELS




Stow the seat belt buckles.




Raise the bottom cushion up while pulling the lever until it locks.


FOLDING - DOUBLE CAB MODELS




Pass the seat belt through the seat belt hangers.



Remove head restraints and lift up the bottom cushion.



Attach the head restraints.




Pull lock release strap and fold down the seatback.


FEATURES & OPERATIONS

Lights & turn signals


HEADLIGHTS

Operating the  switch turns on the headlight indicator .


Type A




Type B



Type C




Low beam (Original position)



Daytime running light (DRL) system

Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night. (The parking brake needs to be released and the headlight switch must be in the “AUTO (type A and C)”, or the “DRL (type B)” position while the vehicle is on.)

Automatic light cut off system

- The light switch is in “AUTO” or “≡D”: The lights will turn off automatically 30 seconds after the vehicle is turned from ON to “LOCK” position** or OFF*** and a door is opened and all of the doors are closed. (If the  switch on the Smart Key remote is pressed after all doors are locked, the lights will turn off immediately.)
- The light switch is in “≡D”: The lights will turn off automatically if the vehicle is turned from ON to “LOCK” position** or OFF*** and the driver’s door is opened.

Automatic High Beams system (AHB)

Automatically switches between high and low beams as appropriate to enhance vision at night.

Refer to Toyota Safety Sense™ P (TSS-P) in this guide or the “Owner’s Manual” for more details on the Automatic High Beams feature.


* Operating conditions must be met. Refer to the “Owner’s Manual” for details.

** Vehicle equipped without a Smart Key system.


*** Vehicle equipped with a Smart Key system.

FRONT FOG LIGHTS (IF EQUIPPED)

TURNING SIGNALS



Front fog lights come on when the parking lights are on or the headlights are on in low beam.




* Move the lever partway and release. The signals will flash three times.


Power windows

Driver side


Type A (driver's side only)



Type B (front seat windows)




Window lock switch



Automatic down (type A)/up or down (type B) operation Press the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.

Window lock switch Deactivates all passenger windows. Driver's window remains operable.


Windshield wipers & washers



* **Intermittent windshield wiper frequency adjustment:** Rotate to increase/decrease wiper frequency.

FEATURES & OPERATIONS


Audio



Refer to the “Navigation and Multimedia System Owner’s Manual” or visit www.toyota.com/audio-multimedia for additional resources.

NOTE: Always use safe driving practices and follow all traffic rules.

Garage door opener (HomeLink®)* (if equipped)



Garage door openers manufactured under license from HomeLink®* can be programmed to operate garage doors, estate gates, security lighting, etc.

Refer to the “Owner’s Manual” for more details.

For programming assistance, contact HomeLink® at 1-800-355-3515, or visit www.homelink.com/toyota.




* HomeLink® is a registered trademark of Gentex Corporation.

Steering wheel switches & telephone controls (Bluetooth®)

“ ^ v ” Use to search within the selected audio feature.

“MODE/HOLD” Press to change audio mode. Press and hold to mute or pause the audio.

Start call




Volume control


Voice command talk switch

End call

Type A (without moonroof)



Type B (with moonroof)




Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel.

Refer to the Bluetooth® device pairing in this guide or the “Navigation and Multimedia System Owner’s Manual” for additional user instructions.

NOTE: Always use safe driving practices and follow all traffic rules.


FEATURES & OPERATIONS

USB media port



Connecting a compatible device and cable into the USB media port will support charging and music playback through the audio multimedia system.

USB charge ports



The vehicle must be in the "ACC" or "ON" position (without Smart Key) / "ACCESSORY" or "IGNITION ON" mode (with Smart Key) for use.

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF. (It is available only on vehicles with automatic transmissions.)

DEFAULT SETTING

Shift position linked door unlocking function

- Doors unlock when shifting into Park.

Speed linked door locking function

- Doors lock when the vehicle speed is approximately 12 mph (20 km/h) or higher.

CUSTOMIZED SETTING

Shift position linked door locking function


- Doors lock when shifting from Park.



Driver's door linked door unlocking function

- (Without a Smart Key) Doors unlock when the driver's door is opened within 10 seconds after turning the ignition switch to the "LOCK" position.
- (With a Smart Key) Doors unlock when the driver's door is opened within 10 seconds after turning the vehicle off.

Refer to the "Owner's Manual" for more details.

Qi Wireless charger (if equipped)

Charging can only be performed with the vehicle in the “ACC” or “ON” position (without Smart Key)/ ACCESSORY or IGNITION ON mode (with Smart Key) and only on mobile devices with the “” logo.





Place device nearest in the center of the charging area for best results. Moving device may result in stopping or restarting the charging process.

A mobile device can be charged wirelessly on the tray. **(1)** Press the wireless charger switch. **(2)** Place a compatible mobile device on the tray as shown in the illustration. An amber indicator illuminates while charging is in progress. When charging is complete, the indicator illuminates green. Some phones, cases or cover type wireless chargers may not cause the green indicator to illuminate even though it is fully charged.


Refer to the “Owner’s Manual” for limitations and more details on this system before attempting to use it.

Power Sliding Rear window (if equipped)



The vehicle must be on for use.

Multi-Information Display (MID)



Enter/Set:
Press to enter/set.
Press and hold to
reset

“◊” and “<>”
Press to select an item/change
pages

Return to the
previous screen

Switch menus/Display top screen

Press MID control switches to change and select information in the following:



Drive information



Navigation system-linked display (if equipped)



Audio system-linked display



Vehicle information (if equipped)



Warning message display




Settings display

Refer to your “Owner’s Manual” for complete details.


Moonroof (if equipped)

SLIDING OPERATION

TILTING OPERATION



Press once to open completely.




Press once to open completely.

Lightly press either side of the moonroof switch while opening/tilting is in progress, the moonroof stops partway.


Air conditioning/heating

AUTOMATIC AIR CONDITIONING (IF EQUIPPED)


Display



Selectors and switches




MANUAL AIR CONDITIONING (IF EQUIPPED)



FEATURES & OPERATIONS


Heated seats (if equipped)



Press to **Hi (ON)**>Mid>Lo>**OFF**

The vehicle must be on for use.

Clock




- 1) Press "**MENU**" button next to the screen.
- 2) Select "**Setup**" or "**General**" in the touchscreen to access the general setting screen.
- 3) Select "**Clock**."
- 4) Select the desired items to be set.


Refer to the "Navigation and Multimedia System Owner's Manual" for more details.

* Premium Audio only

Door lock switches




Power outlet-12V DC



The vehicle must be in the "ACC" or "ON" position (without Smart Key) / "ACCESSORY" or "IGNITION ON" mode (with Smart Key) for use.

Power outlet-120V AC (if equipped)

Main switch




120 V AC/400 W



120 V AC/100 W


Power outlet socket (deck)




The power outlet can be used when the engine is running.

Refer to the "Owner's Manual" for more details.

Trailer lights



Use wire harness to connect trailer lights.




Use service connector for the trailer brake controller.
(With a towing package)

Refer to the "Owner's Manual" for more details.

FEATURES & OPERATIONS

Active traction control (if equipped)




The active traction control system automatically helps prevent the spinning of four wheels when the vehicle is started or accelerated on slippery road surfaces.

Stop the vehicle or reduce your speed to less than 2 mph (3 km/h).

Depress the clutch pedal and turn the four-wheel drive control switch in the "4L" position. Then press the "A-TRAC" switch to activate the system.

Refer to the "Owner's Manual" for limitations and more details on this system before attempting to use it.

AUTO LSD system (if equipped)



At this time, the "AUTO LSD" and VSC off indicators will come on simultaneously.


The AUTO LSD system aids traction by using the traction control system to control hybrid system performance and braking when one of the drive wheels begins to spin.

The system should be used only when one of the drive wheels spinning occurs in a ditch or rough surface.

The system can be used only on 2WD models and in 2WD mode on 4WD models.

Refer to the "Owner's Manual" for limitations and more details on this system before attempting to use it.

Rear differential lock (if equipped)




The rear differential lock system is provided for use only when wheel spinning occurs in a ditch or on a slippery or rugged surface. This system is effective in case one of the rear wheels is spinning.

The following systems do not operate when the rear differential is locked. (ABS/ Brake assist system/VSC/Downhill assist control system*/TRAC)

* If equipped

Refer to your "Owner's Manual" for complete details on this system before attempting to use it.

Vehicle Stability Control (VSC)/TRAC/ Trailer sway control OFF switch




The VSC OFF switch is used to switch between modes related to the TRAC, VSC and Auto LSD functions.

To disable VSC/TRAC/Trailer Sway Control systems, press and hold the switch for at least 3 seconds while the vehicle is stopped.

Refer to the "Owner's Manual" for limitations and more details on this system before attempting to use it.


Steering lock release

Without Smart Key system



When starting the engine, the engine switch may seem stuck in the “LOCK” position. To free it, turn the key while turning the steering wheel slightly left and right.


With Smart Key system



A message will be displayed on the Multi-Information Display (MID).

Check that the shift lever is in P. Press the power button while turning the steering wheel left and right.

Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA) (if equipped)



The Blind Spot Monitor is a system that has two functions:

- The Blind Spot Monitor function (assists the driver in making the decision when changing lanes)
- The Rear Cross Traffic Alert function (assists the driver when backing up)



The system is designed to use radar sensors to detect vehicles traveling in the Tacoma's blind spot. If a vehicle is detected, the driver will be alerted via the outside rear view mirror indicator on the detected side.

Rear Cross Traffic Alert function:

While in reverse, when a vehicle approaching from the right or left rear of the Tacoma is detected, the outside rear view mirror indicators will flash. Also, RCTA buzzer will sound.

Refer to the “Owner’s Manual” for limitations and more details on this system before attempting to use it.

Rear view monitor system




The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is integrated in the tailgate handle.

To adjust the image on the rear view monitor screen, press the "MENU" button and select "Display." Select "Camera" to adjust the screen contrast and brightness.

Refer to the "Navigation and Multimedia System Owner's Manual" for limitations and more details on this system.

Intuitive parking assist (if equipped)



The parking assist sonar system operates when the vehicle approaches an obstacle. The distance from your vehicle to nearby obstacles when parallel parking or maneuvering into a garage is measured by sensors and communicated via the Multi-Information Display (MID) and/or the multimedia display and buzzer.

When the sensor detects an obstacle, the direction and the approximate distance to the obstacle are displayed on the MID and/or the multimedia display by illuminating continuously (far) or blinking (near), and beeping sounds will switch from intermittent to continuous as you approach and get closer to a detected obstacle. When the sensors detect two or more obstacles, the audible alerts will respond to the nearest zone.

Refer to the "Owner's Manual" for limitations and more details.

Quick overview-Toyota Safety Sense™ P (TSS-P)

Toyota Safety Sense™ P (TSS-P) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS-P is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the “Owner’s Manual” for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to www.toyota.com/safety-sense.



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.

The advanced grille-mounted radar system is designed to work with the forward-facing camera to help recognize a preceding vehicle or pedestrian, and provide an alert, mitigation and/or avoidance support in certain conditions.



Lane Departure Alert (LDA)

LDA is designed to provide notification when the system detects an unintended lane departure.



Dynamic Radar Cruise Control (DRCC)

DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed.




Automatic High Beams (AHB)


AHB is designed to detect the headlights of oncoming vehicles and the taillights of preceding vehicles and switch between high beams and low beams as appropriate.

Sensors

TSS-P combines a forward-facing camera mounted in front of the inside rear view mirror and a grille-mounted radar mounted in the front grille. These sensors support the driving assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System with Pedestrian Detection (PCS w/PD) is designed to help detect a vehicle or a pedestrian in certain situations. Using a combination of a camera and radar, PCS w/ PD can provide an audio/visual alert to warn you of a possible collision under certain circumstances. If you don't react, the system is designed to automatically brake.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the pre-collision system yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle or pedestrian may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

See www.toyota.com/safety-sense for more information.

Refer to the Toyota "Owner's Manual" for a list of additional situations in which the system operation may be limited.

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.


Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

TOYOTA SAFETY SENSE™

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS included with the TSS-P package may also help to detect a pedestrian in front of your vehicle using the forward-facing camera and the front grille-mounted radar. The forward-facing camera of PCS detects a potential pedestrian based on size, profile, and motion of the detected pedestrian. However, a pedestrian may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to the Toyota “Owner’s Manual” for additional limitations and information.


CHANGING PCS WARNING TIMING








- (1) Press “<>” switches and select “⚙️” from the Multi-Information Display (MID).
- (2) Press “⏏️” switches and select “🚦 PCS” and then press “⏏️.” The setting screen is displayed.
- (3) Press “⏏️” switches and select “Sensitivity” and then press “⏏️” to change the warning timing. Each time it is pressed, the PCS warning timing changes as shown above.
- (4) Press “➡️” to go back to the menu.

Note: PCS is enabled each time the vehicle is turned on. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same.)


DISABLING PRE-COLLISION SYSTEM (PCS)



- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ PCS” and then press “” to turn PCS on or off.
- (3) Press “” to go back to the menu.

Refer to the Toyota “Owner’s Manual” for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Departure Alert (LDA)




By detecting visible white/yellow lane markings at speeds above 32 mph, Lane Departure Alert (LDA) is designed to issue an audio/visual alert if an inadvertent lane departure is detected.

See www.toyota.com/safety-sense for more information.

Refer to the Toyota “Owner’s Manual” for a list of additional situations in which the system operation may be limited.

TOYOTA SAFETY SENSE™

TURNING THE LDA SYSTEM ON/OFF




Press the LDA switch to turn the LDA system on. Press again to turn it off.


Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

LANE DEPARTURE ALERT


LDA function display



Lane Departure Alert (LDA) indicator flashes orange when operating.




(1)



(2)

LANE DEPARTURE ALERT (CONTINUED)

The LDA function  is displayed when the Multi-Information Display (MID) is switched to the driving support system information display.

- (1) The system displays solid white lines on the LDA indicator when visible lane markers on the road are detected. A lane indicator flashes orange to alert the driver when the vehicle deviates from its lane.
- (2) The system displays outlines on the LDA indicator when lane markers on the road are not detected or the function is temporarily canceled.






Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LDA may not function on the side(s) where white/yellow lines are not detectable.

ADJUSTING LDA ALERT SENSITIVITY

The driver can adjust the sensitivity of the LDA (warning) function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.

Standard - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “<>” switches and select “ LDA” and then press “.
 The setting screen is displayed.- (3) Press “<>” switches and select “ Sensitivity” and then press “.
 to change the desired setting.- (4) Press “↶” to go back to the menu.


Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

TOYOTA SAFETY SENSE™

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.








Gentle swaying from driver's inattentiveness.








Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.

Sway warning is a function of the LDA system and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning display on the MID.

DISABLING SWAY WARNING SYSTEM

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “<>” switches and select “ LDA” and then press “.
 The setting screen is displayed.- (3) Press “<>” switches and select “ Warning” and then press “” to change the desired setting.
- (4) Press “➔” to go back to the menu.

ADJUSTING SWAY ALERT SENSITIVITY

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “<>” switches and select “ LDA” and then press “.
 The setting screen is displayed.- (3) Press “<>” switches and select “ Sensitivity” and then press “” to change the setting.
- (4) Press “➔” to go back to the menu.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.


Refer to the Toyota “Owner’s Manual” for additional information on the LDA system operation, settings adjustments, limitations, and precautions before attempting to use it.

Dynamic Radar Cruise Control (DRCC)

Intended for highway use, Dynamic Radar Cruise Control (DRCC) lets you drive at a preset speed. DRCC is designed to function at speeds of 25-110 mph and uses vehicle-to-vehicle distance control, helping maintain a preset distance from the vehicle ahead of you.


See www.toyota.com/safety-sense for more information.

Refer to the Toyota "Owner's Manual" for a list of additional situations in which the system operation may be limited.



ACTIVATING DRCC

(1)



Press the cruise control main switch to turn DRCC on.
Press it again to turn it off.

Refer to page 39 for switching to Constant Speed (Cruise) Control Mode.

ADJUSTING SET VEHICLE SPEED

(2)



Resume²

(3)

Increase speed



Cancel¹



The vehicle will cruise at a set speed, decelerate to maintain a selected distance from a slower preceding vehicle and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.


(1) Press the ON-OFF button. The "Radar Ready" and " " indicator will come on.
(2) Push the lever down to set speed, push it up to resume and pull it or depress brake to cancel the speed control.

(3) Push up to increase the set speed, push down to decrease (1 mph [1.6 km/h] or 1 km/h [0.6 mph] increments.)


¹ The speed control may also be canceled by depressing the brake pedal.

² The speed control may be resumed once vehicle speed exceeds 25 mph (40 km/h).

ADJUSTING DISTANCE




To change the vehicle-to-vehicle distance:

Press the “” switch to cycle through the settings, which will change progressively.

This mode employs a radar sensor to detect the presence of a preceding vehicle up to approximately 328 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead. These distances vary based on vehicle speed.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control switch.

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears

When a slower vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system may apply the brakes (the brake lights will come on at this time.) The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.


ADJUSTING DISTANCE (CONTINUED)

(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.


SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE



Press and hold the cruise control main "ON-OFF" switch for at least 1.5 seconds to turn on constant speed cruise control. If you are already using DRCC, press the cruise control main "ON-OFF" switch to turn DRCC off before activating constant speed cruise control.

Note: When the engine is turned off, it will automatically default to DRCC.


SETTING CONSTANT SPEED (CRUISE) CONTROL



To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET VEHICLE SPEED on page 37.

Refer to the Toyota "Owner's Manual" for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)






The Automatic High Beams (AHB) safety system is designed to help you see more clearly at night. At speeds above 25 mph, AHB can detect the headlights of oncoming vehicles and taillights of preceding vehicles, then automatically toggles between high and low beams accordingly.

See www.toyota.com/safety-sense for more information.

Refer to the Toyota “Owner’s Manual” for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

- (1) Push the lever away from you with the headlight switch is in the “ ” or “**AUTO**” (if equipped) position.
- (2) Press the “ ” switch.

The AHB indicator “ ” will come on when the headlights are on and the headlight switch lever is in the high beam position to indicate the system is active.

Note: Pull the lever back toward you or press the AHB switch to turn the AHB system off.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY

When all of the following conditions are met, the high beams will be automatically turned on (after approximately 1 second):


- Vehicle speed is approximately 21 mph (34 km/h) or more.
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or taillights turned on.
- There are few streetlights on the road ahead.

If any of the following conditions occur, the high beams will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or taillights turned on.
- There are many streetlights on the road ahead.

SAFETY & EMERGENCY FEATURES


Seat belts




NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the "Owner's Manual".

Seat belts-Shoulder belt anchor



Safety Connect®



Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is staffed with live agents at the Toyota response center, which operates 24 hours per day, 7 days per week.


Services for subscribers include:


- Automatic collision notification
- Stolen vehicle locator
- Emergency assistance ("SOS" button)
- Enhanced roadside assistance

For limitations and additional information, refer to the "Owner's Manual" or visit www.toyota.com/connected-services.

SAFETY & EMERGENCY FEATURES

Tire Pressure Monitoring (warning) System (TPMS)



After adjusting tire pressures, or after tires have been rotated or replaced, turn the vehicle on and press and hold the “SET” button until the indicator blinks three times. Let the vehicle sit for a few minutes to allow initialization to complete. Drive the vehicle at approximately 25 mph (40 km/h) or more for approximately 10 minutes.

The tire pressure detected by the tire pressure warning system can be displayed on the Multi-Information Display (MID). (Available on select grades.)


If the tire pressure indicator flashes for 1 minute and then remains on, take the vehicle to your local Toyota dealer.

Refer to the load label on the door jamb or the “Owner’s Manual” for tire inflation specifications.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

Rear door child safety locks (Double Cab models only)

Rear door




Moving the lever downward will allow the door to be opened only from the outside.


Spare tire & tools

TOOL LOCATION



Double Cab models -under the rear seat



Access Cab models -under the rear seat



REMOVING THE SPARE TIRE



(3)

Turn the jack handle counterclockwise.

Diagram (3) shows the jack handle being turned counterclockwise to lower the jack.

Refer to the "Owner's Manual" for tire changing and jack positioning procedures.

SAFETY & EMERGENCY FEATURES

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC).

Refer to the “Owner’s Manual” for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota’s Anti-lock Brake System detects which wheels are locking up and limits wheel lockup by “pulsing” each wheel’s brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or “panic” braking, and then add braking pressure to help decrease the vehicle’s stopping distance. When there’s only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota’s ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn’t engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

VEHICLE STABILITY CONTROL (VSC)

VSC helps prevent loss of traction during cornering by reducing engine power and applying brake force to selected wheels.

Toyota’s VSC monitors steering angle and the direction your vehicle is traveling. When it senses that the front or rear wheels begin to lose traction, VSC reduces engine power and applies braking to selected wheels. This helps restore traction and vehicle control.

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).




Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Only use one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



GETTING STARTED WITH TOYOTA AUDIO MULTIMEDIA AND CONNECTED SERVICES

- Bluetooth® Pairing
- Toyota app
- Connected Services
- Apple CarPlay®
- Android Auto™
- Amazon Alexa
- SiriusXM®
- Online Support Tool

Scan QR Code to Download Toyota app

Apple




Android




Do not attempt the process while driving.

Bluetooth® Pairing¹



Note:
Do not attempt the Bluetooth® Pairing process while driving.

STEP 1 Press [MENU] on the faceplate, then select “Setup” on display screen.




iPhone Bluetooth Menu

Android Bluetooth Menu

STEP 2 Ensure Bluetooth is turned on for your phone.



STEP 3 Select “Bluetooth,” then select “Add New Device” on display screen.




STEP 4 Select “Phone Name.”



STEP 5 Check the display on your phone. Does the PIN XXXX match the PIN displayed? If it does, select “Pair.”

Bluetooth® Pairing¹ (continued)



STEP 6 “Connecting” displays while phone is forming the connection to the multimedia system.



STEP 7 Enable Notifications (text message). While pairing your phone this message will display: “**You may need to allow message access on your phone.**”

Note: You may also select “**Skip**” on display screen to skip enabling notifications. If skipped, proceed to **STEP 9**.



STEP 8 Turn on “Show Notifications” for iPhone® or “ON” for Android.



STEP 9 A confirmation will appear once your phone has been paired and connected.

Getting Started with Toyota app



TOYOTA

Toyota app allows access to valuable information about your vehicle and control of capable features equipped with your vehicle.

- Manuals & Warranties
- Schedule Maintenance
- Roadside Assistance
- Vehicle Health Report
- SiriusXM® Radio
- Safety Recalls
- Toyota Financial Services - Vehicle Payment

Remote Connect equipped vehicle functions:

- Lock/Unlock
- Start Vehicle
- Vehicle Finder
- Guest Driver settings

Scan QR Code to Download Toyota app.

Apple



Android



Or

Search "Toyota" at your applicable app store.



If you have a Toyota Owner's account, use your credentials to "**Sign In**" and get started with Toyota app.

Or

If you do not have a Toyota Owner's account, "**Register**" now to get started with Toyota app.



Getting Started with Connected Services²


Safety Connect³

- (SOS) EMERGENCY ASSISTANCE BUTTON
- AUTOMATIC COLLISION NOTIFICATION
- ROADSIDE ASSISTANCE
- STOLEN VEHICLE LOCATOR

Remote Connect⁴ (if equipped)


- START VEHICLE
- VEHICLE STATUS ALERTS
- LOCK/UNLOCK VEHICLE DOORS
- VEHICLE FINDER

Authentication is required to enable Remote Connect.




Available on select 2018 and newer vehicles. (Remote Start/Stop is not available on vehicles equipped with Manual Transmission.)


- STEP 1** Press [APPS] on the faceplate, then select “Communications” on display screen.




- STEP 2** Select “Authorization” icon.



- STEP 3** Enter the 6 character authorization code you received via email to enable remote services.



- STEP 4** Select “Submit.”




- STEP 5** The vehicle has been successfully authorized for remote services. Select “OK.”

Service Connect⁵ (if equipped)


- VEHICLE HEALTH REPORT
- VEHICLE MAINTENANCE ALERT NOTIFICATION

Available on select 2018 and newer vehicles.

STEP 1 After registering and opting into Service Connect, you will be greeted with a notification of the following language “**Would you like to start Toyota Service Connect Activation?**”




STEP 2 Select “Yes.”



STEP 3 Select “OK.”

Destination Assist⁶ (if equipped)



Destination Assist provides drivers 24-hour access to a live agent who can provide directions through the vehicle’s factory-installed navigation system to an address or point of interest.

Wi-Fi Connect⁷

Multiple mobile devices

- Connect up to 5 Wi-Fi enabled devices
- Passengers can use smartphones, laptops and tablets

Infotainment

- Browse the internet
- Send and receive email
- Stay connected on social media
- Access favorite apps
- Stream movies




Several factors may affect smartphone and/or system performance *including:*

1. Smartphone operating system software version
2. Smartphone battery power level
3. Poor cellular reception to the smartphone
4. Multiple applications running on a smartphone at the same time
5. Charge/media cable quality
6. Smartphone operating system updates may also affect Toyota app functionality

For additional information, please visit: www.toyota.com/connected-services


Connected Services Online Support



Toyota's online support tool provides intuitive "How-To" instruction and videos. To begin, please visit: <https://toyotaaudioandconnectedservicesupport.com/>

Apple CarPlay® (if equipped)


Setup of Apple CarPlay®



STEP 1 Ensure Siri® is enabled on your phone.



STEP 2 Plug a compatible iPhone® into the USB media port using an Apple® approved cable.




STEP 3 Select "**Always Enable**" to use CarPlay® each time the vehicle is operated.



STEP 4 Select "**Allow**" to use CarPlay® while the phone is locked.

Setup of Apple CarPlay® (continued)



* Screen depiction accurate at time of posting.

STEP 5 Apple CarPlay® is now ready to operate.


Requirements:

Bluetooth® functions will be inoperable while CarPlay® is in use. Wireless CarPlay® is not supported. Features may vary by vehicle model and phone.


To learn more about how your iPhone® works with CarPlay® visit: <https://support.apple.com/en-us/HT205634>

To view a full list of CarPlay® supported apps visit: <https://www.apple.com/ios/carplay/>

Siri® through CarPlay®



Press and hold the voice command talk switch for 2-3 seconds to activate.



* Screen depiction accurate at time of posting.

Once Siri® is activated you can ask to: make calls, send and receive text messages, listen to music and more.

GETTING STARTED WITH

Android Auto™ (if equipped)


Setup of Android Auto™




STEP 1 With Android 9 or below, the Android Auto™ app download is required. With Android 10, Android Auto™ is built in and the app is NOT required.



STEP 2 Open Android Auto™ app and tap get started.




STEP 3 Ensure Android Auto™ is enabled on the phone.



STEP 4 In the Projection Settings screen select Android Auto™ to on.



STEP 5 Plug a compatible Android™ smartphone into the USB media port using an Android approved cable.



STEP 6 Press menu button and then select the Android Auto™ icon.

Setup of Android Auto™ (continued)



* Screen depiction accurate at time of posting.


STEP 7 Android Auto™ is now ready to operate.

Requirements:

Bluetooth® functions will be inoperable while Android Auto™ is in use. Wireless Android Auto™ is not supported. Features may vary by vehicle model and phone.

To learn more about how to use Android Auto™ visit: <https://www.android.com/auto>

Google Assistant through Android Auto™



Press and hold the voice command talk switch for 2-3 seconds to activate.



* Screen depiction accurate at time of posting.

Once Google Assistant is activated, you can ask to: make calls, send and receive text messages, listen to music and more.

GETTING STARTED WITH

Amazon Alexa (if equipped)

Toyota + Alexa Setup



STEP 1 Toyota app and Toyota+Alexa apps are available to download at your app store.



STEP 2 Once Toyota+Alexa has successfully installed, open the app to complete the setup. Tap **"Get started"**.



iPhone users



STEP 3 Depending on your phone and application settings, Toyota+Alexa may automatically sign you in. Otherwise, **"Sign In"** or **"Create a new Amazon account"**.



STEP 4 Tap **"Allow"** for Toyota+Alexa to access Alexa Voice Services and Alexa Account Connection. Allow permissions.



Android users



STEP 3 Depending on your phone and application settings, Toyota+Alexa may automatically sign you in. Otherwise, **"Sign In"** or **"Create a new Amazon account"**.




STEP 4 Tap **"Allow"** for Toyota+Alexa to access Alexa Voice Services and Alexa Account Connection. Tap **"Enable Permissions"**.

Toyota + Alexa Setup



STEP 5 To use the Toyota+Alexa app, your mobile device must be paired to the vehicle via *Bluetooth*[®].



STEP 6 To launch Toyota+Alexa, press “**Apps**” and select “**Toyota+Alexa**”. Toyota+Alexa is now ready. Just say “Alexa” and wait for the tone, then speak your command.

Note: Ensure the Toyota + Alexa app is open on the paired phone.

SiriusXM[®] 8 (If equipped)


SiriusXM[®] Audio



* Screen depiction accurate at time of posting.

Toyota vehicles equipped with SiriusXM[®] come with a 3-month All Access trial subscription. Also enjoy SiriusXM[®] when you're not in your vehicle by linking the vehicle account with the SiriusXM[®] app.





Toyota's online support tool provides intuitive "How-To" instruction and videos.

To begin, please visit: <https://toyotaaudioandconnectedservicesupport.com/>

Privacy & Protection

To learn about Toyota's Connected Services data collection, use, sharing and retention, visit: www.toyota.com/privacyvts.

- ¹ The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage and carrier.
- ² Visit Toyota.com/connected-services or see your local Toyota Dealer for additional details.
- ³ Safety Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, all of which can limit system functionality or availability, including access to response center and emergency support. Stolen vehicle police report required to use Stolen Vehicle Locator. Some features may require the Toyota app. Registration required. Subscription required after trial. Service subject to change at any time without notice. Terms of Use apply. Data charges may apply. Service may vary by vehicle and region. See usage precautions and service limitations in Owner's Manual and Toyota.com/connected-services/ for additional details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁴ Toyota - Remote Connect
Use only if aware of circumstances surrounding vehicle and it is legal and safe to do so (e.g., do not remotely start engine if vehicle is in an enclosed space or vehicle is occupied by a child). Toyota Remote Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, which can limit system functionality and availability. Service may vary by vehicle and region. Registration and Toyota app download required. Subscription required after trial. Terms of Use apply. Data charges may apply. Remote start/stop not available on manual transmission-equipped vehicles. Services subject to change at any time without notice. See usage precautions and service limitations in Toyota Owner's Manual and <https://www.toyota.com/connected-services> for additional details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁵ Service Connect information provided is based on the last time data was collected from the vehicle and is not real time data. Service Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, which can limit functionality or availability. Service may vary by vehicle and region. Registration required. Subscription required after trial. Service subject to change at any time without notice. Terms of Use apply. Data charges may apply. See usage precautions and service limitations in Owner's Manual and Toyota.com/connected-services for additional details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁶ Destination Assist depends on an operative telematics device, a cellular connection, navigation map data and GPS signal strength and other factors outside of Toyota's control, which can limit system ability functionality or availability. Use common sense when relying on this information. Service may vary by vehicle and region. Registration required. Subscription required after trial. Services subject to change at any time without notice. Terms of Use apply. Data charges may apply. See Owner's Manual and Toyota.com/connected-services for additional limitations and details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁷ Wi-Fi Connect is available on select 2018 and newer Toyota vehicles.
Visit Toyota.com/connectedservices for vehicle availability.
- ⁸ SiriusXM® audio services require a subscription sold separately by Sirius XM Radio Inc. To cancel, you must call SiriusXM at 1-866-635-2349. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com.
All fees and programming subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. SiriusXM and all related marks and logos are trademarks of Sirius XM Radio Inc.



TACOMA

Quick Reference Guide 2023



00505QRG23TAC



Printed in U.S.A. 8/22
21-MKG-16287

toyota.com