

PALSGAARD® RECMILK 146

Matcha Rice Tea Latte – Recipe Suggestion



Recipe

	Percentage
Palsgaard® RecMilk 146	0.15
Nutri-MOL ¹	7.50
Palatinose ¹	5.00
Maltodextrin (DE10)	3.00
Exberry Shade Mint Green 54600211 ²	1.00
Matcha Powder ³	0.50
Canola Oil	0.50
Disodium Phosphate	0.05
Sucralose	0.002
Water up to	100.0%

¹From Beneo

²From GNT

³From Gyomu-yo

Composition

	Percentage
Palsgaard® RecMilk 146	0.15
Fat	0.63
Protein	0.60
Total Solids	15.25

Identification: Matcha Rice Tea Latte

Palsgaard Asia-Pacific Pte Ltd – 3 International Business Park #04-18 Nordic European Centre, Singapore 609927 – Phone: +65 6661 0460 – E-mail: pap@palsgaard.com.sg
 The product is tested and recommended for use in mentioned application only. The information given is, to the best of our knowledge, reliable. However, no guarantees are given, not even in case of negligence on the part of Palsgaard A/S, and users of our products, are recommended and advised to conduct their own trials to determine whether our products are suitable for the user's specific purposes. In case of delivery of defective products, the user is only entitled to order a new delivery. Palsgaard A/S assumes no guarantee against patent infringement, liabilities or risks involved from the use of this product or information given.

Procedure

- Hydrate Nutriz MOL at 50°C for 30 minutes.
- Pre-blend Palsgaard® RecMilk 146 with the rest of the dry ingredients and add into the hydrated rice solution.
- Add the fat to the solution while stirring and heat up to 65°C, mix well
- Add colour.
- Add disodium phosphate and adjust pH to 6.7 before UHT.
- Preheat to 65°C - 75°C.
- UHT at 140°C for 4 seconds.
- Homogenise upstream at 150/50 bar.
- Cool to below 25°C and fill aseptically.



ORDER SAMPLES

To order samples of Palsgaard® RecMilk 146, please contact your local Palsgaard office via Palsgaard.com

Identification: Matcha Rice Tea Latte

Palsgaard Asia-Pacific Pte Ltd – 3 International Business Park #04-18 Nordic European Centre, Singapore 609927 – Phone: +65 6661 0460 – E-mail: pap@palsgaard.com.sg
The product is tested and recommended for use in mentioned application only. The information given is, to the best of our knowledge, reliable. However, no guarantees are given, not even in case of negligence on the part of Palsgaard A/S, and users of our products, are recommended and advised to conduct their own trials to determine whether our products are suitable for the user's specific purposes. In case of delivery of defective products, the user is only entitled to order a new delivery. Palsgaard A/S assumes no guarantee against patent infringement, liabilities or risks involved from the use of this product or information given.